




Watershed

- **Watershed (basin):** the area of land where all of the water that is under it or drains off of it goes to the same place
- **Divide:** the boundary of the watershed




Hydrograph

- A chart in which flow rate is plotted vs. time



An example hydrograph for a simple parking lot

Hydrograph



10-year hydrograph for
a creek (example)

- The shape of the hydrograph is affected by various factors such as: precipitation, weather, topography of the watershed, density and type of ground cover, ...

Runoff coefficient

- Runoff coefficient

$$= \{ \text{rate of runoff } (R) \} / \{ \text{rate of precipitation } (P) \}$$

Typical Runoff Coefficients



Description of Area or Character of Surface	Runoff Coefficient	Description of Area or Character of Surface	Runoff Coefficient
Business		Railroad yard	0.20–0.35
Downtown	0.70–0.95	Natural grassy land	0.10–0.30
Neighborhood	0.50–0.70	Pavement	
Residential		Asphalt, concrete	0.70–0.95
Single-family	0.30–0.50	Brick	0.70–0.85
Multi-units, detached	0.40–0.60	Roofs	0.75–0.95
Multi-units, attached	0.60–0.75	Lawns, sandy soil	
Residential, suburban	0.25–0.40	Flat (<2%)	0.05–0.10
Apartment	0.50–0.70	Average (2–7%)	0.10–0.15
Industrial		Steep (>7%)	0.15–0.20
Light	0.50–0.80	Lawns, heavy soil	
Heavy	0.60–0.90	Flat (<2%)	0.13–0.17
Parks, cemeteries	0.10–0.25	Average (2–7%)	0.18–0.22
Playgrounds	0.20–0.35	Steep (>7%)	0.25–0.35

The more developed, the bigger runoff coefficient

Source: Joint Committee of the American Society of Civil Engineers and the Water Pollution Control Federation, 1969.

Runoff coefficient

Copyright © The McGraw-Hill Companies, Inc. Permission required for reproduction or display.



$$Q_c > Q_b > Q_a, \quad t_c < t_b < t_a$$

- Urban & industrial development increases the impact of flood

Runoff coefficient

Q: A watershed with an area of 4530 km^2 received 77.7 cm of precipitation in 2013. The average rate of flow measured in a river which drained the watershed was $39.6 \text{ m}^3/\text{s}$. Infiltration occurred at an average rate of $9.2 \times 10^{-7} \text{ cm/s}$ and evapotranspiration was estimated to be 45 cm/year . What was the change in storage in the watershed in 2013? What was the runoff coefficient?

Low impact development (LID)

- A developing area of study and practice
- A land planning and engineering design approach to minimize the hydrological impact of urban development
- Some effect on the treatment of stormwater pollutants is also expected



An LID project in Seattle, USA
(<http://www.mapc.org>)

LID practices


- Bioretention zone

Grass buffer strips: reduce the velocity of runoff, filter particulate matter

Plants: take up nutrients, transpiration

Organic layer: support microbial growth (organic material degradation), sorb pollutants

Planting soil: water retention, sorb pollutants



<http://www.georgiastormwater.com>

LID practices

- Green roofs



LID practices

- Permeable pavements
 - sidewalks, bike roads, parking lots
- Grass swales and channels
 - Redirect runoff from stormwater drains
- Rain barrels, cisterns
 - Collection of stormwater and use for irrigation / toilet flushing




Grass swale in Ottawa, Canada
(<http://www.ottawa.ca>)

Reading assignment

- Textbook Ch 7, p. 263-266, 296-298

Groundwater hydrology

Copyright © The McGraw-Hill Companies, Inc. Permission required for reproduction or display.




Groundwater hydrology

- Unsaturated zone (vadose zone): the voids in the soils are partially filled with water (the remaining portion is filled with air)
- Saturated zone: all voids in the soils are filled with water
- Groundwater: the water in the saturated zone
- Aquifer: the geologic formation through which water can flow horizontally and be pumped (ex: sand, sedimentary rocks, limestone, etc.)

Groundwater hydrology


- Hyporheic zone
 - A region beneath and alongside a stream bed, where there is mixing of shallow groundwater and surface water
 - Important for:
 - Exchange of substances (e.g., nutrients, dissolved O₂, contaminants) between groundwater and surface water
 - Aquatic ecosystem – e.g., fish spawning, benthic invertebrates, microbes



<http://www.madrimasd.org>


Unconfined aquifer

- **Unconfined aquifer:** an aquifer of which upper surface of its saturated zone is not confined by an impermeable layer
- **Water table:** The upper surface of the saturated zone in an unconfined aquifer
- **Capillary fringe:** the zone where capillary action occurs (the soil draws water above the water table)



Confined aquifer

Copyright © The McGraw-Hill Companies, Inc. Permission required for reproduction or display.




- **Confined aquifer:** an aquifer bounded by impermeable layers (called as confining layers) both at the top and the bottom
- Confining layers: *aquicludes* or *aquitards*

Piezometric head and surface

- Piezometer: a small tube device installed vertically into an aquifer
- Piezometric head: the height of the water in a piezometer → a measure of the pressure
- Piezometric surface: an imaginary plane drawn through the piezometric head of several piezometers

Piezometric head and surface



- Unconfined aquifer: piezometric surface = water table
- Confined aquifer: piezometric surface is higher than the top end of the aquifer

Groundwater flow

- Keep in mind that:
 - (Of course) surface water flows from higher to lower elevation
 - Groundwater flows from areas of higher head to lower head
- Hydraulic gradient, $\Delta h/L$

$$\frac{\Delta h}{L} = \frac{h_2 - h_1}{L}$$

h_2 = the head at location 2

h_1 = the head at location 1

L = the linear distance between location 1 and 2

Darcy's Law

$$v = K \frac{\Delta h}{L}$$

v = Darcy velocity (specific discharge) [L/T]

K = hydraulic conductivity [L/T]

The flow velocity is proportional to the hydraulic gradient and the hydraulic conductivity

In terms of the flow rate of groundwater,

$$Q = vA = \left(K \frac{\Delta h}{L} \right) A$$



Q = flow rate [L³/T]

A = cross-sectional area [L²]

Darcy's Law

Darcy's velocity $v = Q/A$

This is **NOT** a real velocity: the groundwater flows only through the voids (pores), not the entire cross-sectional area



Seepage velocity & porosity

- The average linear velocity (**seepage velocity**), v'

$$v' = \frac{v}{\eta} \quad \eta = \text{porosity [-]}$$

- Porosity: the ratio of the volume of voids (pores) in the aquifer material to the total volume

Typical values of aquifer parameters

Aquifer Material	Porosity (%)	Typical Values for Hydraulic Conductivity ($m \cdot s^{-1}$)
Clay	55	2.3×10^{-9}
Loam	35	6.0×10^{-6}
Fine sand	45	2.9×10^{-5}
Medium sand	37	1.4×10^{-4}
Coarse sand	30	5.2×10^{-4}
Sand and gravel	20	6.0×10^{-4}
Gravel	25	3.1×10^{-3}
Slate	<5	9.2×10^{-10}
Granite	<1	1.2×10^{-10}
Sandstone	15	5.8×10^{-7}
Limestone	15	1.1×10^{-5}
Fractured rock	5	$1 \times 10^{-8} - 1 \times 10^{-4}$

Sources: Davis, M., D. A. Cornwell. *Introduction to Environmental Engineering*, 3rd ed. McGraw-Hill, New York (1998). Todd, D. A. *Groundwater Hydrology*, 2nd ed. John Wiley and Sons, New York (1980)

Groundwater flow

Q: While investigating the ground near Bldg. 35, you found water at 7 m below ground surface (bgs). One hundred meters away, you found water at 7.5 m bgs. Choose the datum as 25 m bgs. The aquifer is coarse sand which has a porosity of 30% and the hydraulic conductivity of 5.2×10^{-4} m/s. The cross-sectional area of the aquifer is 925 m². Determine the i) piezometric surface at each point, ii) the direction of groundwater flow, iii) the hydraulic gradient, iv) the Darcy velocity, v) the flow rate, and vi) the seepage velocity.

Reading assignment

Textbook Ch 7 p. 276-285