

Potential flow

Flow of a Real Fluid







Chapter 7 Flow of a Real Fluid

Contents

- 7.0 Introduction
- 7.1 Laminar Flow
- 7.2 Turbulent Flow and Eddy Viscosity
- 7.3 Fluid Flow Past Solid Boundaries
- 7.4 Characteristics of Boundary Layers
- 7.5 The Laminar Boundary Layer*
- 7.6 The Turbulent Boundary Layer*
- 7.7 Separation
- 7.8 Secondary Flow





Chapter 7 Flow of a Real Fluid

- 7.9 Flow Establishment
- 7.10 Shear Stress and Head Loss
- 7.11 The First Law of Thermodynamics for Real Fluid
- 7.12 Velocity Distribution
- 7.13 Separation Internal Flow
- 7.14 Secondary Flow– Internal Flow
- 7.15 Navier-Stokes Equation for Two-Dimensional Flow*
- 7.16 Applications of the Navier-Stokes Equations*





Objectives

- Introduce the concepts of laminar and turbulent flow
- Examine the condition under which laminar and turbulent flow occur
- Introduce influence of solid boundaries on qualitative views





7.0 Introduction

- Ideal fluid
- In Chs.1 ~ 5, the flow of an ideal incompressible fluid was considered.
- Ideal fluid was defined to be inviscid, devoid of viscosity.
- There were no frictional effects between moving fluid layers or between the fluid and bounding walls.
- Real Fluid
- Viscosity introduces <u>resistance to motion</u> by causing shear or friction forces between fluid particles and between these and boundary walls.
- For flow to take place, work must be done against these resistance forces.
 In this process energy is converted into heat (mechanical energy loss).





	Ideal (inviscid) fluid	Real (viscous) fluid
Viscosity	inviscid	viscous
Velocity profile	uniform (slip condition)	non-uniform (no-slip)
Eq. of motion	Euler's equation	Navier-Stokes equation
		(Nonlinear, 2nd-order P.D.E)
Flow	_	Laminar flow
Classification		Turbulent flow





- Laminar flow
- Agitation of fluid particles is a molecular nature only.
- Length scale ~ order of mean free path of the molecules
- Particles appear to be constrained to motion in parallel paths by the action of viscosity.
- Viscous action damps disturbances by wall roughness and other obstacles.
 - \rightarrow stable flow
- The shearing stress between adjacent layers is

$$\tau = \mu \frac{dv}{dy}$$











- Turbulent flow
- Fluid particles do not retain in layers, but move in heterogeneous fashion through the flow.
- Particles are sliding past other particles and colliding with some in an entirely <u>random or chaotic</u> manner.
- Rapid and continuous macroscopic mixing of the flowing fluid occurs.
- Length scale of motion >> molecular scales in laminar flow





Chapter 7 Flow of a Real Fluid







7.0 Introduction







- Two forces affecting motion
- (i) Inertia forces, F_I
- ~ acceleration of motion

$$F_I = M a = \rho l^3 \left(\frac{V^2}{l}\right) = \rho V^2 l^2$$

(ii) Viscous forces, F_V

$$F_{V} = \tau A = \mu \frac{dV}{dy} l^{2} = \frac{\mu V l^{2}}{l} = \mu V l$$





7.1 Laminar flow

• Reynolds number R_e

$$R_{e} = \frac{F_{I}}{F_{V}} = \frac{\rho V^{2} l^{2}}{\mu V l} = \frac{\rho V l}{\mu} = \frac{V l}{\mu / \rho} = \frac{V l}{v}$$
$$\mu = \text{dynamic viscosity} \qquad (\text{kg m}^{-1}\text{s}^{-1})$$
$$v = \frac{\mu}{\rho} = \text{kinematic viscosity} \qquad (\text{m}^{2}/\text{s})$$

- Inertia forces are dominant \rightarrow turbulent flow (unstable)
- Viscous forces are dominant \rightarrow laminar flow (stable)
- Reynolds dye stream experiments
 low velocity → low Reynolds number → laminar flow
 high velocity → high Reynolds number → turbulent flow



Critical velocity

upper critical velocity: laminar \rightarrow turbulent lower critical velocity: turbulent \rightarrow laminar

- Critical Reynolds number
 - (i) For pipe flow

$$R_{e} = \frac{Vd}{v}, \quad d = \text{pipe diameter}$$

$$(7.1)$$

$$R_{e} < 2100 \rightarrow \text{laminar flow} \quad \cdots \quad \text{lower critical} \quad R_{c1} = 2100$$

$$2100 < R_{e} < 4000 \rightarrow \text{transition} \quad \cdots \quad \text{upper critical} \quad R_{c2} = 4000$$

$$R_{e} \gg 4000 \rightarrow \text{turbulent flow}$$





7.1 Laminar flow





103. Repetition of Reynolds' dye experiment. Osborne Reynolds' celebrated 1883 investigation of stability of flow in a tube was documented by sketches rather than photography. However the original apparatus has survived at the University of Manchester. Using it a century later, N. H. Johannest and C. Lowe have taken this sequence of photographs. In laminar flow a filament of colored water introduced at a bell-shaped entry extends undisturbed the whole length of the glass tube. Transition is seen in the second of the photographs as the speed is increased; and the last two photographs show fully turbulent flow. Modern traffic in the streets of Manchester made the critical Reynolds number lower than the value 13,000 found by Reynolds.

61





(ii) Open channel flow: $R_e < 500 \rightarrow \text{laminar flow}$

$$R_{c} = \frac{Vd}{v} = \frac{V(4R)}{v} = 2100 \qquad \therefore R_{c} = \frac{VR}{v} \cong 500$$
$$R = \text{hydraulic radius} = A = \frac{\pi d^{2}/4}{\pi d} = \frac{d}{4}$$

(iii) Flow about a sphere: $R_e < 1 \rightarrow \text{laminar flow}$

where V = approach velocity; d = sphere diameter





7.1 Laminar flow

• Experiment for two flow regimes















[IP 7.1] p. 233 Water at 15°C flows in a cylindrical pipe of 30 mm diameter. $v = 1.339 \times 10^{-6} \text{ m}^2/\text{s} \leftarrow \text{water at } 15^{\circ}\text{C}$ p.694 A. 2.4b

Find largest flow rate for which laminar flow can be expected.

[Sol]

Take $R_{c} = 2100$ as the conservative upper limit for laminar flow

(a) For water

$$R_{c} = 2100 = \frac{Vd}{v} = \frac{V(30/10^{3})}{1.139 \times 10^{-6}}$$
$$V_{water} = 0.080 \text{ m/s}$$
$$Q_{water} = 0.0805 \left(\frac{\pi}{4}(0.03)^{2}\right) = 5.69 \times 10^{-5} \text{ m}^{3}/\text{s}$$





(b) For air

$$v_{air} = 1.46 \times 10^{-5} \text{ m}^2/\text{s}$$

 $(\mu_{air}/\rho = 1.8 \times 10^{-5} \text{ pa} \cdot \text{s} / 1.225 \text{ kg/m}^3)$
 $V_{air} = 1.022 \text{ m/s}$
 $Q_{air} = 7.22 \times 10^{-4} \text{ m}^3/\text{s} \approx 13 Q_{water}$
 $\mu_{air} < \mu_{water}$

 $V_{c,air} > V_{c,water}$





- Turbulent flow
- Turbulence is found in the atmosphere, in the ocean, in most pipe flows, in rivers and estuaries, and in the flow about moving vehicles and aircrafts.
- Turbulence is generated primarily by <u>friction effects at solid boundaries</u> or by the <u>interaction of fluid streams that are moving past each other</u> <u>with different velocities</u> (shear flow).





- Characteristics of turbulent flow (Tennekes & Lumley, 1972)
 - ① Irregularity or randomness in time and space
 - ② Diffusivity or rapid mixing \rightarrow high rates of momentum and heat transfer
 - ③ High Reynolds number
 - ④ 3D vorticity fluctuations \rightarrow 3D nature of turbulence
 - ⑤ Dissipation of the kinetic energy of the turbulence by viscous shear stresses
 - [Energy cascade: energy supply from mean flow to turbulence]
 - ⁽⁶⁾ Continuum phenomenon even at the smallest scales
 - ⑦ Feature of fluid flows, not a property of fluids themselves





Decomposition of turbulent flow

 $v_{x}(t) = \overline{v} + v_{x}'$ $v_{y}(t) = \overline{v} + v_{y}'$

$$v(t) =$$
 instantaneous turbulent velocity
 $\overline{v} =$ time mean velocity $= \frac{1}{T} \int_0^T v(t) dt$

 v_x' = turbulent fluctuation in *x*-direction

 v_{y} = turbulent fluctuation in *y*-direction

$$\overline{v_x} = \frac{1}{T} \int_0^T v_x dt = 0$$
$$\overline{v_y} = 0$$



















rms =
$$\sqrt{(v'_x)^2} = \left[\frac{1}{T}\int_0^T {v'_x}^2 dt\right]^{1/2}$$

• relative intensity of turbulence
$$=\frac{\sqrt{\overline{v_x'}^2}}{\overline{v}}$$

• Mean time interval, T

T = times scale = meaningful time for turbulence fluctuations

- air flow: $10^{-1} \sim 10^{0}$ sec
- pipe flow: $10^{-1} \sim 10^{0}$ sec
- open flow: $10^{\circ} \sim 10^{1}$ sec





- ~ measure of the scale of the turbulence
- maximum size of the turbulent eddies ∞ size of boundary
- ~ order of (pipe radius, channel width or depth, boundary layer thickness)
- \rightarrow The intensity of turbulence increases with velocity, and <u>scale of</u> <u>turbulence</u> increases with boundary dimensions.







[Re] Measurement of turbulence

- (i) Hot-wire anemometer
- ~ use laws of convective heat transfer
- ~ Flow past the (hot) sensor cools it and decrease its resistance and output voltage.
- ~ record of random nature of turbulence
- (ii) Laser Doppler Velocitymeter (LDV)
- ~ use Doppler effect
- (iii) Acoustic Doppler Velocitymeter (ADV)
- (iv) Particle Image Velocimetry (PIV)















































- Turbulence
- Because turbulence is an entirely chaotic motion of small fluid masses, motion of individual fluid particle is impossible to trace.
- \rightarrow Mathematical relationships may be obtained by considering the average motion of aggregations of fluid particles or by statistical methods.
- Shearing stresses in turbulent flow










Let time mean velocity $v = \overline{v}$ Thus, velocity gradient is $\frac{dv}{dy}$

Now consider momentum exchange by fluid particles moved by turbulent fluctuation

Mass moved to the lower layer tends to <u>speed up</u> the slower layer

Mass moved to the upper layer tends to <u>slow down</u> the faster layer

 \rightarrow This is the same process as if there were a <u>shearing stress between</u> <u>two layers</u>.





- Problem of useful and accurate expressions for turbulent shear
- stress in terms of mean velocity gradients and other flow properties
 - 1) Boussinesq (1877)
- ~ suggest the similar equation to laminar flow equation

$$\tau = \varepsilon \frac{dv}{dy} \tag{7.2}$$

- \mathcal{E} = eddy viscosity
 - = property of flow (not of the fluid alone)
 - = f (structure of the turbulence, space)

$$\tau_{total} = \left(\mu + \varepsilon\right) \frac{dv}{dy}$$

where μ = viscosity action, \mathcal{E} = turbulence action







2) Reynolds (1895)

~ suggest the turbulent shear stress with time mean value of the product of $v_x v_y$

$$\tau = -\rho \overline{v_x v_y}$$
 ~ Reynolds stress

 v_x = fluctuating velocity along the direction of general mean motion

 v_{y} = fluctuating velocity normal to the direction of general mean motion

$$v_x v_y$$
 = time mean value of the product of $v_x v_y$

$$= \frac{1}{T} \int v_x v_y dt$$





• Prandtl (1926)

- ~ propose that small aggregations of fluid particles are transported by turbulence a certain mean distance, /, from regions of one velocity to regions of another.
- ~ termed the distance as the mixing length
- → Prandtl's mixing length theory

$$\tau = \rho \, l^2 \left(\frac{dv}{dy}\right)^2$$

where l = mixing length = f(y)





(7.3)

Comparing Eqs. (7.2) and (7.3) gives



- Flow near the boundary wall
- ~ turbulence is influenced by the wall = wall turbulence

$$l = \kappa y \tag{7.5}$$

where $\kappa = \text{von Karman constant} \approx 0.4$; y = distance from wall

$$\tau = \rho \,\kappa^2 \, y^2 \left(\frac{dv}{dy}\right)^2$$

(7.6)

(7.4)





[IP 7.2] p. 238 Laminar flow

Show that if laminar flow is <u>parabolic velocity profile</u>, the shear stress profile must be a straight line.

[Sol]

$$\tau = \mu \frac{dv}{dy}$$

$$v = C_1 y^2 + C_2 \quad \rightarrow \text{ parabolic}$$

$$\frac{dv}{dy} = 2 C_1 y$$

 $\therefore \quad \tau = 2 \ C_1 \ \mu \ y = C \ y \quad \rightarrow \quad \text{straight line}$











[IP 7.3] p. 238 Turbulent flow in a pipe

A turbulent flow of water occurs in a pipe of 2 m diameter.

$$v = 10 + 0.8 \ln y$$

 $\tau \Big|_{y=1/3m} = 103 \text{ Pa}$

Calculate \mathcal{E} , l, κ







7.2 Turbulent Flow and Eddy Viscosity

Solution:

$$\tau = \varepsilon \frac{dv}{dy}$$

$$= \rho l^2 \left(\frac{dv}{dy}\right)^2$$

$$= \rho \kappa^2 y^2 \left(\frac{dv}{dy}\right)^2$$

$$\frac{dv}{dy}\Big|_{y=1/3m} = \frac{0.8}{y}\Big|_{y=1/3m} = 2.4 \ s^{-1}$$

- (a): $103 = \varepsilon (2.4)$ $\varepsilon = 42.9 \text{ Pa} \cdot \text{s}$
- (b): $103 = 10^3 l^2 (2.4)^2$ $l = 0.134 \text{ m} \approx 10\%$ of pipe radius

(c):
$$103 = 10^3 \kappa^2 \left(\frac{1}{3}\right)^2 (2.4)^2 \qquad \kappa = 0.401$$





7.3 Fluid Flow Past Solid Boundaries

- Flow phenomena near a solid boundary
- external flows: flow around an object immersed in the fluid

(over a wing or a flat plate, etc.)

- internal flows: flow between solid boundaries

(flow in pipes and channels)





- (1) Laminar flow over smooth or rough boundaries
- ~ possesses essentially the same properties, the velocity being zero at the

boundary surface and the shear stress throughout the flow

- ~ <u>surface roughness has no effect on the flow</u> as long as the roughness are small relative to the flow cross section size.
- \rightarrow <u>viscous effects dominates</u> the whole flow





7.3 Fluid Flow Past Solid Boundaries







(2) Turbulent flow over smooth or rough boundaries

- Flow over a smooth boundary is always separated from the boundary by

a sublayer of viscosity-dominated flow (laminar flow).

[Re] Existence of laminar sublayer

Boundary will reduce the available mixing length for turbulence motion.

 \rightarrow In a region very close to the boundary, the available mixing length is reduced to zero (i.e., the turbulence is completely extinguished).

 \rightarrow a film of viscous flow over the boundary results in.





7.3 Fluid Flow Past Solid Boundaries

- Shear stress:

Inside the viscous sublayer: $\tau = \mu \frac{dv}{dy}$ Outside the viscous sublayer: $\tau = \rho l^2 \left(\frac{dv}{dy}\right)^2$

- Between the turbulent region and the viscous sublayer lies a transition <u>zone in which shear stress results</u> from a complex combination of both turbulent and viscous action.

 \rightarrow The thickness of the viscous sublayer varies with time. The sublayer flow is unsteady.





7.3 Fluid Flow Past Solid Boundaries





(b) Rough boundary





- Roughness of the boundary surface affects the physical properties (velocity, shear, friction) of the fluid motion.
- \rightarrow The effect of the roughness is dependent on the relative size of roughness and viscous sublayer.
- Classification of surfaces based on ratio of absolute roughness e to viscous sublayer thickness δ_v
- i) Smooth surface: $\frac{e}{\delta_{u}} \le 0.3$
- Roughness projections are completely submerged in viscous sublayer.
- \rightarrow They have no effect on the turbulence.





ii) Transition: $0.3 < \frac{e}{\delta_v} < 10$ iii) Rough surface: $10 \le \frac{e}{\delta}$

- However, the thickness of the viscous sublayer depends on certain properties of the flow.

→ The same boundary surface behave as a smooth one or a rough one depending on the size of the Reynolds number and of the viscous sublayer.

$$\delta_{v} = f\left(\frac{1}{R_{e}}\right)$$

 $i > v \uparrow \rightarrow R_{e} \uparrow \rightarrow \delta_{v} \downarrow \rightarrow \text{rough surface}$
 $ii > v \downarrow \rightarrow R_{e} \downarrow \rightarrow \delta_{v} \uparrow \rightarrow \text{smooth surface}$





- Boundary layer concept by Prandtl (1904)
 - Inside boundary layer frictional effects
 - Outside boundary layer frictionless (irrotational) flow
- Mechanism of boundary layer growth
 - ① Velocity of the particle at the body wall is zero.
 - ② Velocity gradient (dv/dy) in the vicinity of the boundary is very high.
- ③ Large frictional (shear) stresses in the boundary layer $(\tau = \mu (dv/dy))$ slow down successive fluid elements.
 - ④ Boundary layers steadily thicken downstream along the body.











- Flow over a <u>smooth</u> flat plate
- \rightarrow Boundary layer flow: laminar \rightarrow transition \rightarrow turbulent
- Laminar boundary layer
- ~ Viscous action is dominant.

$$R_{x} = \frac{V_{0}x}{v} \qquad R_{x_{c}} = 500,000$$
(7.7a)
$$R_{\delta} = \frac{V_{0}\delta}{v} \qquad R_{\delta_{c}} = 4,000$$
(7.7b)

 $R_x < 500,000$ or $R_{\delta} < 4,000 \rightarrow$ laminar boundary layer expected











- Turbulent boundary layer
- ~ Laminar sublayer exists.

 $R_x > 500,000$ or $R_{\delta} > 4,000$

• Differences between Figs. 7.19 and 7.18

i) For the streamlined body, its surface has a curvature that may affect the boundary layer development either due to inertial effect or induced separation if the body is particularly blunt.











(ii) For the streamlined body, the velocity in the irrotational flow (no vorticity) just outside the boundary layer, changes continuously along the body because of the disturbance to the overall flow offered by the body of finite width.

$$\xi = 0$$
 ; $\xi = \frac{d\Gamma}{dxdy} = 2\omega = \frac{\partial v}{\partial x} - \frac{\partial u}{\partial y}$





7.7 Separation

- Separation of moving fluid from boundary surfaces is important difference between ideal (inviscid) and real flow.
- Ideal fluid flow: no separation

symmetrical streamline

• Flow of real fluid: separation, eddy, wake

asymmetric flowfields

[Re] Eddy:

- unsteady (time-varying)
 - forming, being swept away, and re-forming
 - absorbing energy from the mean flow and dissipation it into heat





7.7 Separation







7.7 Separation

• Surface of discontinuity divide the live stream from the adjacent and more moving eddies.

 \rightarrow Across such surfaces there will be a high velocity gradient and high shear stress.

- \rightarrow no discontinuity of pressure
- \rightarrow tend to break up into smaller eddies (Fig. 7.22b)





7.7 Separation







7.7 Separation



24. Circular cylinder at <u>R=1.54</u>. At this Reynolds number the streamline pattern has clearly lost the foreand-aft symmetry of figure 6. However, the flow has not yet separated at the rear. That begins at about R=5, though the value is not known accurately. Streamlines are made visible by aluminum powder in water. Photograph by Sadatoshi Taneda



25. Sphere at R=9.8. Here too, with wall effects negligible, the streamline pattern is distinctly asymmetric, in contrast to the creeping flow of figure 8. The fluid is evidently moving very lowly at the rear, making it difficult to estimate the onset of separation. The flow is presumbly attached here, because separation is believed to begin above R=20. Streamlines are shown by magnesium cuttings illuminated in water. Photograph by Maddeline Contanzeau and Michele Floymt by

20





7.7 Separation



40. Circular cylinder at R=9.6. Here, in contrast to figure 24, the flow has clearly separated to form a pair of recirculating eddies. The cylinder is moving through a tank of water containing aluminum powder, and is illuminated by a sheet of light below the free surface. Extrapolation of such experiments to unbounded flow suggests separation at R=4 or 5, whereas most numerical computations give R=5 to 7. Photograph by Sadatoshi Taneda



41. Circular cylinder at R=13.1. The <u>standing eddles</u> become elongated in the flow direction as the speed increases. Their length is found to increase linearly with Reynolds number until the flow becomes unstable above R=40. Taneda 1956a

28



42. Circular cylinder at R=26. The downstream distance to the cores of the eddies also increases linearly with Reynolds number. However, the lateral distance between the cores appears to grow more nearly as the square root. Photograph by Sadatoshi Taneda





7.7 Separation





7.7 Separation

• Free streamline:

Under special circumstances the streamlines of a surface of discontinuity

become free streamline.

Along the free streamline, the pressure is constant.

Separation point

The prediction of separation may be simple for sharp-cornered obstructions.

However, prediction is more complex matter for gently curved (streamlined) objects or surfaces.





7.7 Separation







7.7 Separation

 \rightarrow The analytical prediction of separation point location is an exceedingly difficult problem.

- \rightarrow Thus, it is usually obtained more reliably from experiments.
- For small ratio of thickness to length \rightarrow no separation (Fig. 7.21) For large ratio of thickness to length \rightarrow separation (Fig. 7.22)





7.7 Separation






7.7 Separation

Proceeding from <u>A to B</u>, the pressure falls because the flow is accelerating.

 \rightarrow This produces a favorable pressure gradient which strengthens the boundary layer.

From <u>*B* to *C*</u>, the pressure rises as the flow decelerates because the body is thinning.

 \rightarrow This produces an adverse (unfavorable) pressure gradient which weakens the boundary layer sufficiently to cause separation.





7.7 Separation

- Acceleration of real fluids tends to be an efficient process, deceleration an inefficient one.
- Accelerated motion: stabilize the boundary layer, minimize energy dissipation
- Decelerated motion: promote separation, instability, eddy formation, and large energy dissipation





Another consequence of wall friction is the creation of a flow within a flow, a secondary flow superposed on the main primary flow.

- Secondary flow occurring at the cross section of the meandering river:
 Fig. 7.28a)
- 2) Horseshoe-shaped vortex around the bridge pier: Fig. 7.28b)
- Downward secondary flow from A to B induces a vortex type of motion, the core of the vortex being swept downstream around the sides of the pier.
 This principle is used on the wings of some jet aircraft, vortex generators being used to draw higher energy fluid down to the wing surface to forestall large-scale separation.





7.8 Secondary Flow







7.9 Flow Establishment - Boundary layers

- At the entrance to a pipe, viscous effects begin their influence to lead a growth of the boundary layer.

- Unestablished flow zone (미확립흐름구간):
- ~ dominated by the growth of boundary layers accompanied by diminishing core of irrotational fluid at the center of the pipe
- Established flow zone (확립흐름구간):
- ~ Influence of wall friction is felt throughout the flow field.
- ~ There is no further changes in the velocity profiles.
- ~ Flow is everywhere rotational.
- Flow in a boundary layer may be laminar if $R_e \left(=\frac{Vd}{v}\right) < 2100$ or turbulent if $Re \ge 2100$.





7.9 Flow Establishment - Boundary layers

1) Laminar flow

x = length of unestablished flow zone

$$\frac{x}{d} \approx \frac{R_e}{20} \left(\approx \frac{2100}{20} \approx 100 \right)$$

Thus, $x < 100 d \rightarrow$ unestablished flow











7.9 Flow Establishment - Boundary layers

2) Turbulent flow

• Comparison of flat plate boundary layers (Fig. 7.28) with those of the pipe entrance (Fig. 7.16): For the pipe entrance:

(1) The plate has been rolled into a cylinder so it is not flat.

(2) The <u>core velocity steadily increases downstream</u> whereas the corresponding free stream velocity of Fig. 7.28 remains essentially constant.

(3) The <u>pressure in the fluid diminishes</u> in a downstream direction whereas for the flat plate there is no such pressure variation.





7.9 Flow Establishment - Boundary layers







81/100







82/100

What is the effect of the friction forces on the boundary of a control volume, such as the inside of a pipe? \rightarrow The <u>impulse-momentum equation provides</u> a clear answer.

- Wall shear stress τ_0 is a basic resistance to flow.
- ~ acting on the periphery of the streamtube opposing the direction of the fluid motion
- ~ cause energy dissipation (energy loss = h_L)





Now, apply impulse-momentum equation between ① & ② along the direction of streamtube

Pressure
force
$$\sum \vec{F} = Q\rho(\vec{V_2} - \vec{V_1})$$
$$pA - (p + dp)A - \tau_0 Pdl - (\gamma + \frac{d\gamma}{2})Adl\frac{dz}{dl}$$
$$= (V + dV)^2 A(\rho + d\rho) - V^2 A\rho$$
Shear force is included
for real fluid.

in which P = perimeter of the streamtube





Assume momentum correction factor, $\beta_1 = \beta_2 = 1$

Neglect smaller terms containing products of differential quantities

$$-dpA - \tau_0 P dl - \gamma A dz = 2A\rho V dV + AV^2 d\rho$$
$$= A \left\{ \rho d \left(V^2 \right) + V^2 d\rho \right\} = A d \left(\rho V^2 \right)$$

Divide by $A\gamma$



For established incompressible flow, g is constant; $d(1/\gamma) = 0$

$$d\left(\frac{p}{\gamma} + \frac{V^2}{2g} + z\right) = -\left(\frac{\tau_0 dl}{\gamma R_h}\right)$$

Integrating this between points 1 and 2 yields

$$\left(\frac{p_1}{\gamma} + \frac{V_1^2}{2g} + z_1\right) - \left(\frac{p_2}{\gamma} + \frac{V_2^2}{2g} + z_2\right) = \frac{\tau_0 \left(l_2 - l_1\right)}{\gamma R_h}$$
(7.8)

Now, note that the difference between total heads is the drop in the energy line between points 1 and 2. Thus, Eq. (7.8) can be rewritten as

$$\frac{p_1}{\gamma} + \frac{V_1^2}{2g} + z_1 = \frac{p_2}{\gamma} + \frac{V_2^2}{2g} + z_2 + h_{L_{1-2}}$$
(7.9)

 \rightarrow Work-energy equation for real fluid flow







caused by the viscous shear stresses."

Distribution of shear stress in the pipe flow











88/100

Consider the streamtube of radius r

 $\begin{aligned} \tau_0 &\to \tau \\ R_h &\to \frac{r}{2} \\ h_{L_{1-2}} &\to h_L \\ l_2 - l_1 &\to l \end{aligned} \qquad \left(\begin{array}{c} R_h = \frac{P}{A} = \frac{\pi r^2}{2\pi r} = \frac{r}{2} \\ R_h = \frac{r}{2\pi r} = \frac{r}{2\pi r} \\ R_h = \frac{r}$

Substituting these into (7.10) gives

$$\tau = \left(\frac{\gamma h_L}{2l}\right) r \tag{7.11}$$

 \rightarrow The shear stress in the fluid <u>varies linearly with distance</u> from the centerline of the pipe.

~ applicable to both laminar and turbulent flow in pipes





[IP 7.6] p. 262 Water flow in a rectangular conduit

Water flows in a 0.9 m by 0.6 m rectangular conduit.

$$\Delta l = 60 \text{ m}$$
$$\Delta h_L = 10 \text{ m}$$

Calculate the resistance stress exerted between fluid and conduit walls.

[Sol]

$$\tau_{0} = \frac{\gamma R_{h}}{\Delta l} \Delta h_{L}$$

$$R_{h} = \frac{A}{P} = \frac{0.9 \times 0.6}{2(0.9 + 0.6)} = \frac{0.54}{3} = 0.18 \text{ m}$$

$$\therefore \quad \tau_{0} = \frac{9.8 \times 10^{3} \times 0.18}{60} \cdot 10 = 0.29 \text{ kPa}$$





- ~ Flow is not axi-symmetric
- \rightarrow τ_0 is mean shear stress on the perimeter

[IP 7.7] p. 262 Water flow in a cylindrical pipe Water flows in a cylindrical pipe of 0.6 m in diameter.

$$\tau_0 = \frac{\gamma h_L}{2\Delta l} R = \frac{(9.8 \times 10^3)}{2(60)} \frac{0.6}{2} = 0.25 \text{ kPa}$$
$$\tau = \tau_0 \frac{r}{R}$$

au in the fluid at a point 200 mm from the wall:

$$\tau \Big|_{r=100\,\text{mm}} = \tau_0 \frac{(0.3 - 0.2)}{0.3} = \frac{1}{3} (0.25) = 0.083 \text{ kPa}$$





Relationship between shear stresses and energy dissipation

$$\frac{dQ}{dt} + \frac{dW}{dt} = \frac{dE}{dt}$$
(7.12)

where dQ = heat transferred to the system

- dW = work done on the system
- dE = change in the total energy of the system

Fig. 7.33 compared to Fig. 5.8

 $dW_{shear} \neq 0$





7.11 The First Law of Thermodynamics for Real Fluid







7.11 The First Law of Thermodynamics for Real Fluid

• General energy equation for steady incompressible flow

$$\left(\frac{p_1}{\gamma} + \frac{V_1^2}{2g} + z_1\right) + E_p = \left(\frac{p_2}{\gamma} + \frac{V_2^2}{2g} + z_2\right) + E_T + h_{L_{1-2}}$$
(7.13)

[Cf] Eq.(5.47): work-energy eq. for ideal fluid

where
$$h_{L_{1-2}} = \frac{\tau_0 (l_2 - l_1)}{\gamma R_h} = \frac{1}{g} (ie_2 - ie_1 - q_H)$$

 $ie =$ internal energy per mass
 $q_H = \frac{1}{\dot{m}} \frac{dQ}{dt} =$ heat added to the fluid per unit of mass

 \rightarrow head loss is a conversion of energy into heat





In a real fluid flow, the shearing stresses produce velocity distributions.

 \rightarrow non-uniform velocity distribution

[Cf] Uniform distribution for ideal fluid flow

Total kinetic energy flux
$$(J/s) = \frac{\rho}{2} \iint v^3 dA$$
 (7.14)
Total momentum flux(N) = $\rho \iint_A v^2 dA$ (7.15)





7.12 Velocity Distribution







7.12 Velocity Distribution

[Re]
$$K.E. = \frac{1}{2}mv^2 = \frac{1}{2}\rho volv^2$$

 $K.E./time = \frac{1}{2}\rho \frac{vol}{t}v^2 = \frac{1}{2}\rho Qv^2 = \frac{1}{2}\rho Avv^2 = \frac{1}{2}\rho Av^3$
momentum flux $= \frac{mv}{t} = \rho \frac{vol}{t}v = \rho Qv = \rho Av^2$

Use mean velocity V and total flow rate Q

Total kinetic energy
$$= \alpha Q \gamma \frac{V^2}{2g} = \frac{\gamma}{2g} Q V^2 \alpha = \frac{\rho}{2} Q V^2 \alpha$$
 (7.16)
Momentum flux $= \beta Q \rho V$ (7.17)

where α , β = correction factors





7.12 Velocity Distribution

(1) Energy correction factor Combine (7.14) and (7.16)

$$\frac{\rho}{2} \alpha Q V^2 = \frac{\rho}{2} \int_A v^3 dA$$
$$\alpha = \frac{1}{V^2} \frac{\int_A v^3 dA}{Q} = \frac{1}{V^2} \frac{\int_A v^3 dA}{\int_A v dA}$$

where $Q = \int_A v dA$

(2) Momentum correction factor

Combine (7.15) and (7.17)

$$\beta Q \rho V = \rho \int_{A} v^{2} dA$$
$$\beta = \frac{1}{V} \frac{\int_{A} v^{2} dA}{Q} = \frac{1}{V} \frac{\int_{A} v^{2} dA}{\int_{A} v dA}$$



7.12 Velocity Distribution

[Ex] $\alpha = \beta = 1$ for uniform velocity distribution

 $\alpha = 1.54$, $\beta = 1.20$ for parabolic velocity distribution (laminar flow)

$$v = v_c \left(1 - \frac{r^2}{R^2} \right)$$

 α =1.1 , $~\beta$ =1.05 ~ for turbulent flow

- Correction in the Bernoulli equation in real fluid flow
- \rightarrow nonuniform velocity distribution
- → bundle of energy lines
- → use single effective energy line of aggregation of streamlines = $\alpha \frac{V^2}{2g}$

$$\alpha_1 \frac{V_1^2}{2g} + \frac{p_1}{\gamma} + z_1 = \alpha_2 \frac{V_2^2}{2g} + \frac{p_2}{\gamma} + z_2 + h_{L_{1-2}}$$
(7.18)

where $h_{L_{1-2}}$ = head loss between sections 1 and 2



Homework Assignment

Homework Assignment #7

Due: 1 week from today

- Prob. 7.1
- Prob. 7.7
- Prob. 7.12
- Prob. 7.17
- Prob. 7.52
- Prob. 7.58
- Prob. 7.69



