Innovative Ship and Offshore Plant Design

Part I. Ship Design

Ch. 1 Introduction to Ship Design

Spring 2019

Myung-Il Roh

Department of Naval Architecture and Ocean Engineering
Seoul National University

Contents

Ch. 1 Introduction to Ship Design

1. Basic Functions of a Ship
2. Main Terminology
3. Comparisons of a Ship with Other Structures
4. Construction Procedure of a Ship

1. Basic Functions of a Ship

Basic Requirements of a Ship



(1) Ship should float and be stable in sea water.

➡ Weight of the ship is equal to the buoyancy* in static equilibrium.

Ship stability

(2) Ship should transport cargoes.

Ship compartment design

➡ The inner space should be large enough for storing the cargoes.

(3) Ship should move fast to the destination and be possible to control itself.

Hull form design, Ship hydrodynamics, Propeller design, Ship maneuverability and control

➡ Shape: It should be made to keep low resistance (ex. streamlined shape).

➡ Propulsion equipment: Diesel engine, Helical propeller

➡ Steering equipment: Steering gear, Rudder



(4) Ship should be strong enough in all her life.

➡ It is made of the welded structure of steel plate (about 10~30mm thickness) and stiffeners.

Ship structural mechanics, Structural design & analysis

* Archimedes' Principle: The buoyancy of the floating body is equal to the weigh of displaced fluid of the immersed portion of the volume of the ship.

Basic Functions of a Ship

☑ **Floating in the water**

- Static equilibrium

☑ **Containing like a strong bowl**

- Welded structure of plates (thickness of about 20 ~ 30mm), stiffeners, and brackets
- A VLCC has the lightweight of about 45,000 ton and can carry crude oil of about 300,000 ton.

☑ **Going fast on the water**

- Hull form: Streamlined shape having small resistance
- Propulsion: Diesel engine, Helical propeller
- The speed of ship is represented with knot(s). 1 knot is a speed which can go 1 nautical mile (1,852 m) in 1 hour.
- A ship has less motion for being comfortable and safe of passengers and cargo.
- Maneuvering equipment: Rudder

How does a ship float? (1/3)

☑ The force that enables a ship to float ➡ " "

- It is .
- It has a magnitude equal to which is .





7

How does a ship float? (2/3)

☑ Archimedes' Principle

- The magnitude of the buoyant force acting on a floating body in the fluid is equal to the weight of the fluid which is displaced by the floating body.
- The direction of the buoyant force is opposite to the gravitational force.

Buoyant force of a floating body
= the weight of the fluid which is displaced by the floating body ("Displacement")
➡ Archimedes' Principle

☑ Equilibrium State ("Floating Condition")

- Buoyant force of the floating body
  = Weight of the floating body

∴ =

G: Center of gravity
B: Center of buoyancy
W: Weight, Δ: Displacement
ρ: Density of fluid
V: Submerged volume of the floating body (Displacement volume, ∇)



8

How does a ship float? (3/3)

(Δ) = Buoyant Force = (W)

$$\Delta = L \cdot B \cdot T \cdot C_B \cdot \rho$$

$$= W = LWT + DWT$$

T: Draft
C_B: Block coefficient
ρ: Density of sea water
LWT: Lightweight
DWT: Deadweight

☑ **Weight = Ship weight (Lightweight) + Cargo weight(Deadweight)**



2. Main Terminology

Principal Dimensions (1/2)



☑ LOA (Length Over All) [m]: Maximum Length of Ship

[m]

- A.P.: After perpendicular (normally, center line of the rudder stock)
- F.P.: Inter-section line between designed draft and fore side of the stem, which is perpendicular to the baseline

☑ Lf (Freeboard Length) [m]: Basis of freeboard assignment, damage stability calculation
- 96% of Lwl at 0.85D or Lbp at 0.85D, whichever is greater

☑ Rule Length (Scantling Length) [m]: Basis of structural design and equipment selection
- Intermediate one among (0.96 Lwl at Ts, 0.97 Lwl at Ts, Lbp at Ts)

Principal Dimensions (2/2)



- B (Breadth) [m]: Maximum breadth of the ship, measured amidships
  - B_{molded}: excluding shell plate thickness
  - $B_{extreme}$: including shell plate thickness
- D (Depth) [m]: Distance from the baseline to the deck side line
  - D_{molded}: excluding keel plate thickness
  - $D_{extreme}$: including keel plate thickness
- Td (Designed Draft) [m]: Main operating draft
  - In general, basis of ship's deadweight and speed/power performance
- Ts (Scantling Draft) [m]: Basis of structural design
- Air Draft [m]: Distance (height above waterline only or including operating draft) restricted by the port facilities, navigating route, etc.
  - Air draft from baseline to the top of the mast
  - Air draft from waterline to the top of the mast
  - Air draft from waterline to the top of hatch cover
  - …

What is a “Hull form”?

that is streamlined in order to satisfy requirements of a ship owner such as a deadweight, ship speed, and so on

- **Like a skin of human**

☑ **Hull form design**

- **Design task that designs the hull form**

Hull form of the VLCC(Very Large Crude oil Carrier)

Wireframe model



Surface model



Lines of a 320K VLCC

Body Plan





Water Plan

Sheer Plan



Hull Form Coefficients (1/2)



= Displacement / (L x B x T x Density)
where, density of sea water = 1.025 [Mg/m^3]



- C_M (Midship Section Coefficient)
  = A_M / (B x T)
- C_P (Prismatic Coefficient)
  = Displacement / (A_M x L x Density)

Hull Form Coefficients (2/2)



- C_{WP} (Water Plane Area Coefficient)
  = A_{WP} / (L x B)

What is a "Compartment"?

- It is divided by a bulkhead which is a diaphragm or peritoneum of human.

☑ **Compartment design (General arrangement design)**

- Compartment modeling + Ship calculation

☑ **Compartment modeling**

- Design task that divides the interior parts of a hull form into a number of compartments
- Design task that evaluates whether the ship satisfies the required cargo capacity by a ship owner and, at the same time, the international regulations related to stability, such as MARPOL and SOLAS, or not



Compartment of the VLCC

17

G/A of a 320K VLCC



Principal Dimensions		Capacities	
LOA	332.0 m	Cargo tank	357,000 m³
LBP	320.0 m	Water ballast	101,500 m³
B	60.0 m		
D	30.5 m	Main Engine	SULZER 7RTA84T-D
Td / Ts	21.0 / 22.5 m	MCR	39,060 PS x 76.0 rpm
Deadweight at Ts	320,000 ton	NCR	35,150 PS x 73.4 rpm
Service speed at Td at NCR with 15% sea margin	16.0 knots	No. of cargo segregation	Three (3)
		Cruising range	26,500 N/M

* Reference: DSME

Innovative Ship and Offshore Plant Design, Spring 2019, Myung-Il Roh

sydlab SEOUL NAT'L UNIV.

18

What is a “Hull Structure”?

comprising of a number of hull structural parts such as plates, stiffeners, brackets, and so on

- Like a skeleton of human

☑ **Hull structural design**

- Design task that determines the specifications of the hull structural parts such as the size, material, and so on

Hull structure of the VLCC



Structural Drawing of a 320K VLCC



Web Frame Drawing

Midship Section (Ordinary Frame Section) Drawing

What is a “Outfitting”?

to be required for showing all function of the ship

- Hull outfitting: Propeller, rudder, anchor/mooring equipment, etc.
- Machinery outfitting: Equipment, pipes, ducts, etc. in the engine room
- Accommodation outfitting: Deck house (accommodation), voyage equipment, etc.
- Electric outfitting: Power, lighting, cables, and so on

■ Like internal organs or blood vessels of human

☑ **Outfitting design**

■ Design task that determines the types, numbers, and specifications of outfitting

Pipe model of the VLCC



P&ID of a 320K VLCC

P&ID: Piping & Instrumentation Diagram, Non-scaled drawing representing the relationship between equipment



Criteria for the Size of a Ship

- Weight of water displaced by the ship's submerged part
- Equal to
- Used when representing the size of

. Actually, Cargo payload + Consumables (F.O., D.O., L.O., F.W., etc.) + DWT Constant

- Used when representing the size of (tanker, bulk carrier, ore carrier, etc.)

- Total volume of ship
- Basis for statics, tax, etc.
- Used when representing the size of

* F.O.: Fuel Oil, D.O.: Diesel Oil, L.O.: Lubricating Oil, F.W.: Fresh Water

Weight and COG (Center Of Gravity)

[ton]

- Weight of water displaced by the ship's submerged part

(DWT) [ton]: Cargo payload + Consumables (F.O., D.O., L.O., F.W., etc.) + DWT Constant
= Displacement - Lightweight

☑ Cargo Payload [ton]: Weight of loaded cargo at the loaded draft

☑ DWT Constant [ton]: Operational liquid in the machinery and pipes, provisions for crew, etc.

(LWT) [ton]: Total of hull steel weight and weight of equipment on board

☑ Trim: difference between draft at A.P. and F.P.
- Trim = {Displacement x (LCB - LCG)} / (MTC x 100)

☑ LCB: Longitudinal Center of Buoyancy

☑ LCG: Longitudinal Center of Gravity

* F.O.: Fuel Oil, D.O.: Diesel Oil, L.O.: Lubricating Oil, F.W.: Fresh Water

Tonnage

☑ **Tonnage: normally,**

- **Basis of various fee and tax**
  : Total sum of the volumes of every enclosed space
- **NT (Net Tonnage): Total sum of the volumes of every cargo space**
  - **GT and NT should be calculated in accordance with "IMO 1969 Tonnage Measurement Regulation".**
- **CGT (Compensated Gross Tonnage)**
- **Panama and Suez canal have their own tonnage regulations.**

[Reference] Old Conversion Factor between GT and CGT

船種 \ 船型(DWT)	100–4,000	4,000–10,000	10,000–30,000		30,000–50,000	50,000–80,000	80,000–160,000	160,000–250,000	250,000 이상	비 고
Crude oil carrier	1.70	1.15	0.75		0.60	0.50	0.40	0.30	0.25	Single hull tanker
	1.85	1.30	0.85		0.70	0.55	0.45	0.35	0.30	Double hull tanker
Product carriers & Chemical carriers	2.30	1.60	1.05		0.80	0.60	0.55			Black product carrier White product carrier
Bulk C+arriers	1.60	1.10	0.70		0.60	0.50	0.40	0.30		Chip carrier, Lumber Carrier, Car/bulk, Bulk/container, Open bulk
Combined carriers	1.60	1.10	0.90		0.75	0.60	0.50	0.40		Ore/bulk/oil
General Cargo Ships	1.85	1.35	1.00		0.75	0.60	0.50	0.40		Semi–container, Multi–purpose cargo
Reefers	2.05	1.50	1.25							
Full container ships	1.85	1.20	10,000–20,000	20,000–30,000	0.75	0.65				
			0.90	0.80						
Ro–Ro vessels	1.50	1.05	0.80	0.70	0.65					
Car carriers	1.10	0.75	0.65	0.55	0.45					Ro–Ro/Container
L.P.G. carriers	2.05	1.60	1.15	0.90	0.80	0.70				
L.N.G. carriers	2.05	1.60	1.25	1.15	1.00	0.75				

船種 \ 船型(GT)	100–1,000	1,000–3,000	3,000–10,000	10,000–20,000	20,000–40,000	40,000–60,000	60,000 이 상	비 고
Ferries	3.00	2.25	1.65	1.15	0.90			
Passenger ships	6.00	4.00	3.00	2.00	1.60	1.40	1.25	
Fishing vessels	4.00	3.00	2.00					Fishing vessel & Fish factory ship
Other non–cargo vessels	5.00	3.20	2.00	1.50				Tug & Supply vessel, Dredger, Ice breaker, Cable layer, Research ship, etc

註 : 100GT 이상 선박

[Reference] New Conversion Factor between GT and CGT

- ☑ Previous method was based on CGT coefficients, depending on type and deadweight of ships.
- ☑ New method is based on formula.
- ☑ Instead of deadweight as base for the choice of the coefficients, the method is based on gross tonnage.

$$CGT = A \cdot GT^{B}$$

where,
GT: Declared gross tonnage of the ship
A: Factor representing the influence of ship type
B: Factor representing the influence of ship size

Ship Type	A	B
Oil Tanker (D/H)	48	0.57
Chemical Tankers	84	0.55
Bulk Carriers	29	0.61
Combined Carriers	33	0.62
General Cargo	27	0.64
Reefers	27	0.68
Full Container	19	0.68
RO-RO Vessels	32	0.63
Car Carriers	15	0.70
LPG Carriers	62	0.57
LNG Carriers	32	0.68
Ferries	20	0.71
Passenger Ships	49	0.67
Fishing Ships	24	0.71
NCCV	46	0.62

* Clarksons, Universal Ship Measurement, 2011

Speed and Power (1/2)

- ☑ MCR (Maximum Continuous Rating) [PS x rpm]
  - ■ NMCR (Nominal MCR)
  - ■ DMCR (Derated MCR) / SMCR (Selected MCR)

[PS x rpm]

- ☑ Trial Power [PS x rpm]: Required power without sea margin at the service speed (BHP)

[%]: Power reserve for the influence of storm seas and wind including the effects of fouling and corrosion.

[knots]: Speed at NCR power with the specific sea margin (e.g., 15%)

Speed and Power (2/2)

- ☑ **DHP: Delivered Horse Power**
  - **Power actually delivered to the propeller with some power loss in the stern tube bearing and in any shaft tunnel bearings between the stern tube and the site of the torsion-meter**
- ☑ **EHP: Effective Horse Power**
  - **Required power to maintain intended speed of the ship**
- ☑ **η_D: Quasi-propulsive coefficient = EHP / DHP**
- ☑ **RPM margin**
  - **To provide a sufficient torque reserve whenever full power must be attained under unfavorable weather conditions**
  - **To compensate for the expected future drop in revolutions for constant-power operation**

Unit (1/2)

- ☑ **LT (Long Ton, British) = 1.016 [ton], ST (Short Ton, American) = 0.907 [ton], MT (Metric Ton, Standard) = 1.0 [ton]**
- ☑ **Density ➡ [ton/m^3 or Mg/m^3]**
  - **e.g., , density of fresh water = 1.0 [ton/m^3], density of steel = 7.8 [ton/m^3]**
- ☑ **1 [knots] = 1 [NM/hr] = 1.852 [km/hr] =**
- ☑ **1 [PS] = 75 [kgf·m/s] = 75×10^{-3} [Mg]·9.81 [m/s^2]·[m/s]**
  = (Pferdestarke, German translation of horsepower)
  - **NMCR of B&W6S60MC: 12,240 [kW] = 16,680 [PS]**
- ☑ **1 [BHP] = 76 [kgf·m/s] = 76×10^{-3} [Mg]·9.81 [m/s^2]·[m/s]**
  = (British horsepower)

Unit (2/2)

- ☑ SG (Specific Gravity) ➡ No dimension
  - SG of material = density of material / density of water
  - e.g., SG of sea water = 1.025, SG of fresh water = 1.0, SG of steel = 7.8
- ☑ SF (Stowage Factor) ➡ [ft^3/LT]
  - e.g., SF = 15 [ft^3/LT] ➡ SG = 2.4 [ton/m^3]
- ☑ API (American Petroleum Institute) = (141.5 / SG) - 131.5
  - e.g., API 40 ➡ SG = 0.8251
- ☑ 1 [barrel] =
  - e.g., 1 [mil. barrels] = 159,000 [m^3]

3. Comparisons of a Ship with Other Structures

Features of a Ship

☑ **Comparison with Other Structures (Building, Automobile, Airplane)**

- **Objective:** vs. living
- **Moving or fixed:** vs. fixed
- **External force acting on the structure:** vs. wind force, frictional force, etc.
- **Design concept:** vs. one design
- **Production method:** vs. mass production

Hull Form Design vs. Car Exterior Design



❑ Hull form design
• A hull form is related to **the resistance and propulsion performance** of a ship.
• Order production: new design for each order
• Large structure of about 100~400 m length
• **The performance like speed and deadweight is most important**.

❑ Car exterior design
• A exterior is related to **the air resistance and esthetic design** of a car.
• Mass production: one time design for each model
• Small structure of about 3~5 m length
• **The performance and esthetic design are simultaneously important**.

Procedure of Car Exterior Design



Procedure of Hull Form Design



* CFD: Computational Fluid Dynamics, CAE: Computer-Aided Engineering

4. Construction Procedure of a Ship

Construction Procedures of a Ship (Overview)

5 key events of construction procedures

* Deadweight 300,000 ton VLCC, L: 320.0 m, B: 58.0 m, D: 31.2 m,
3 soccer fields can be located on the deck.
* 63 building in Seoul, 249.0 m from the ground



* Reference: DSME



Design
(Initial/Detailed/Production)

Construction period of 300K VLCC
(on December 2006)

Key Event	Duration
Contract	-6 months
S/C or W/C*	Base date
K/L	+3 months
L/C	+6 months
D/L	+8 months
Total	14 months

* W/C: Work Commence. Starting date when S/C is made.



Steel Cutting



Assembly



Outfitting



Painting



Erection



Launching

Construction Procedures of a Ship (Detailed)

: 5 key events of construction procedures



* S/C: Steel Cutting, K/L: Keel Laying, L/C: Launching, D/L: Delivery
* BOM: Bill Of Material, POR: Purchase Order Request, QA: Quality Assurance, QC: Quality Control

Construction Procedures of a Ship (Detailed)



Design

Initial Design
- Hull Form Modeling of a 300,000 ton VLCC





* 서정우, 강성찬, 임중현, 이규열, 이상욱, 조두연, **노명일**, "조선 전용 CAD 시스템: EzSHIP", 2003년도 한국CAD/CAM학회 학술발표회, pp.23-28, 서울, 2003.2.7

Initial Design
- Compartment Modeling of a 300,000 ton



* Principal dimensions
Lbp: 320.0m, B: 58.0m, D: 31.2m, Td: 20.8m, Ts: 20.8m, Cb: 0.8086

Compartment

- A space to load cargoes in the ship and divided by bulkheads
- It is like a diaphragm or peritoneum of human.

* Kyu-Yeul Lee, Sang-Uk Lee, Doo-Yeoun Cho, **Myung-Il Roh**, Seong-Chan Kang, Jung-Woo Seo, "An Innovative Compartment Modeling and Ship Calculation System", International Marine Design Conference(IMDC) 2003, pp.683-694, Athens, Greece, 2003.5.7

43

Initial Design (Hull Structure)
- Hull Structural Modeling of a 300,000 to[illegible]



Inside cargo hold part

Hull Structure

- A frame of the ship comprising of a number of hull structural parts such as plates, stiffeners, brackets, and so on
- It is like a skeleton of human.

Midship region

* Principal dimensions
Lbp: 320.0m, B: 58.0m, D: 31.2m, Td: 20.8m, Ts: 20.8m, Cb: 0.8086

* **Myung-Il Roh**, Kyu-Yeul Lee, "An Initial Hull Structural Modeling System for Computer-Aided Process Planning in Shipbuilding", Advances in Engineering Software, Vol. 37, No. 7, pp.457-476, 2006.7

44

Initial Design (Hull Structure)
- Structural Analysis Modeling of a 300,000 DWT VLCC

Contract | Steel Cutting | Keel Laying | Launching | Delivery
Design | Assembly | Erection | Quay Work
Piling Up & Preprocess | Pre-outfitting & Painting
Pre-erection



Global structural analysis model



Hold structural analysis model

Structural Analysis

- A task to assess structural strength of a ship
- It is normally based on finite element method.

* **Myung-Il Roh**, Kyu-Yeul Lee, Woo-Young Choi, Seong-Jin Yoo, "Improvement of Ship Design Practice Using a 3D CAD Model of a Hull Structure", Robotics and Computer-Integrated Manufacturing Journal(SCIE/IF:0.699), 2006.10.16[Article in Press, e-Journal Available]

Initial Design (Pipe Outfitting)
- P&ID (Piping and Instrument Diagram)

Contract | Steel Cutting | Keel Laying | Launching | Delivery
Design | Assembly | Erection | Quay Work
Piling Up & Preprocess | Pre-outfitting & Painting
Pre-erection

P&ID: Piping & Instrumentation Diagram, Non-scaled drawing representing the relationship between equipment

Sea water cooling system



* Sea water cooling system: Piping system that cools fresh water cooler for cooling various devices in the ship with seawater

Detail/Production Design (Hull Structure) - Result of Detailed/Production Design



Detail design: the stage which detailed specification and performance are determined and detailed drawings for each system are generated

Example of a detailed structural drawing of the fore body



Production design: the stage which production drawings (cutting, nesting, piece, and installation drawings) for production of each block are generated



Example of a cutting drawing



Example of a nesting drawing

Detail Design (Pipe Outfitting) - Pipe Modeling of a 300,000 ton VLCC





* **Myung-Il Roh**, Kyu-Yeul Lee, Woo-Young Choi, "Rapid Generation of the Piping Model Having the Relationship with a Hull Structure in Shipbuilding", Advances in Engineering Software(SCIE/IF:0.371), 2006.12.1 [Article in Press, e-Journal Available Now]

Block Division (Production Planning)



Block division drawing of a deadweight 300,000 ton VLCC

* Deadweight 300,000 ton VLCC, L: 320.0 m, B: 58.0 m, D: 31.2 m, 3 soccer fields can be located on the deck.
* 63 building in Seoul, 249.0 m from the ground



* Block seam: Joint line or welding line between adjacent blocks

Piling Up and Preprocess of Steel Material

Piling Up and Preprocess of Steel Material - Piling Up of Steel Material



- ☑ Steel material consists of plates and section steels which have the shape of bar.
- ☑ Piling up: Process of transporting steel material purchased from steel companies to sea or land and storing it in stockyard
- ☑ Grouping: Process of sorting steel material according to the specification and production schedule of each ship, and then supplying it to the preprocess shop
- ☑ Piling up method: "Using Pallet"



Types of section steels

Piling Up and Preprocess of Steel Material - Preprocess of Steel Material



- ☑ Process for removing the rust on the surface of steel material through shot blasting and shop priming
  - ■ Shot blasting: Task to remove rust and mill scale by shooting abrasive (shot ball, cut wire, etc.) to the surface of steel material at high speed
  - ■ Shop priming: Task to paint shop primer on steel material that shot blasting is completed to prevent rust during manufacturing/assembly process

Shot blasting

Shop priming

Types of shots



Shot ball

Cut wire

* Mill scale: A thin, black layer of metal oxide on the surface when heating the metal in the atmosphere

Piling Up and Preprocess of Steel Material - Marking



☑ **Marking:** **for cutting, bending, and assembly processes**

Example of path generation system for marking torch using optimization technique



Example of manual marking line for assembly



➡ How can we minimize the trajectory of marking torch in the NC (Numerical Control) marking?
➡ Example of application of optimization technique

Example of auto-nesting system using optimization technique



* Nesting: Process to minimize the remnants of the steel sheet which are cut and cut by rotating the member pieces in order to use the standard steel sheet most effectively
➡ How can we automatically obtain the nesting result that maximizes the yield (the ratio of the area of the steel sheet to the area of the standard steel sheet)?
➡ Another application of optimization technique

Steel Cutting (S/C)

Steel Cutting (S/C)



☑ Cutting: Process for to obtain a member of the desired shape

☑ Steel Cutting (S/C) or Work Commencement (W/C): Steel cutting for the first time (called groundbreaking ceremony)

☑ Cutting methods: Gas cutting, Plasma cutting, Laser cutting, Edge milling, etc.

* CNC: Computer Numerical Control


Steel cutting using CNC flame cutting machine


Steel cutting using CNC plasma cutting machine


Steel cutting using edge milling machine (Hyundai Samho Heavy Industries)

* Gas cutting: When the steel is heated to a temperature (800-900 deg) at which the oxidation reaction is likely to occur, an exothermic reaction occurs and iron oxide is formed. At this time, cut the plate by supplying high-pressure oxygen.
* Plasma cutting: When an electric arc discharge occurs in air, hydrogen, gas, etc., the gas is partially plasmaized. It is shrunk by a thermophysical method so that the maximum temperature reaches 20,000-30,000 deg. Using it, dissolve and blow the steel with high pressure gas.
* Laser cutting: Melt locally by injecting the light after amplifying and densifying it and by blowing the steel out with high-pressure gas, and cut the steel
* Edge milling: Still cutting using industrial diamond

55

Plate Forming



☑ Plate forming: Process for

- ■ Cold forming: Causing plastic deformation of the plate by applying mechanical force at room temperature
  - ● Forming of a simple primary curved surface (curvature in one direction) by using bending roller or hydraulic press
  - ● Step before hot forming
- ■ Hot forming: Bending the plate using the property of shrinking the steel when it is locally heated and then cooled
  - ● Line heating
    - – Forming a secondary curved surface (curvature exists in two directions) to obtain permanent deformation by applying high temperature heat to the plate
    - – Currently, most of the shipyards in the world are using the second curved surface as a forming method, but they depend entirely on the manual work of the operator due to the difficulty of automation.

Cold processing using bending rollers


Line heating by operator

Assembly

Assembly
- Sub-assembly/Assembly



☑ **Sub-assembly**
- **Process for manufacturing a small-sized part constituting a block**

☑ **Assembly**
- **Process for assembling sub-assembly blocks to make a large block**
- **Process in which about 60% or more of shipbuilding workload is processed**
- **Depending on the shape of the block, it can be classified into the panel block process and the curved block process.**

  – **Approximately 80% of total assembly**
  – **The shape of blocks and inner parts is relatively simple and automation system is adopted.**
  – **Matrix (Egg Box) method, Line welder method, Slit method, Piece by piece method**

  – **Approximately 20% of total assembly**
  – **It is difficult to adopt an automation system due to various shapes and complexity of blocks.**
  – **Line welder method, Piece by piece method**

Example of sub assembly blocks



Example of assembly blocks

Panel block (double bottom block)



Curved block (after body block)



Pre-outfitting and Pre-painting

Pre-outfitting and Pre-painting



☑ **Pre-outfitting**
- Process for to avoid congestion in the latter part of the construction period
- Categorized into block outfitting, unit outfitting, and erection outfitting

☑ **Pre-painting**
- Painting in the preprocess of steel material: "Shop priming"
- Painting in the assembly process: "Pre-painting"
  - Perform block pre-process before preceding pre-painting
- Painting in the erection process: "Erection painting"
  - Perform additional pre-process and painting work on joints between mounting blocks


Pre-outfitting in the double bottom block







Painting in the erection process

Block Preprocess



☑ **Process of removing the rust on the surface of the plate during the assembly process before the preceding painting**

- **Consisting of blasting, air blowing, and grit recovery**
- **Blasting: Removing rust by spraying a small piece of iron (grit) onto the plate**
- **Air blowing: Drop grit on the top of a stiffener to the floor using air**
- **Grit recovery: Collecting grit, dust, etc. on the floor**



Man-hours for block preprocess of double bottom block of VLCC
(For working area of about 4,000m², surface roughness of SA2.5)
- Blasting: 16 people X 3.5H = 56M/H
- Air blowing: 8 people X 1H = 8M/H
- Grit recovery: 8 people X 1.5H = 12M/H

Pre-erection

Pre-Erection

☑ Intermediate process between assembly and erection processes to increase erection efficiency

☑ This process makes "one large PE (Pre-Erection) block" by combining two or more hull blocks and outfitting near dock



Keel Laying (K/L)

Keel Laying (K/L)



☑ The event when . That means the starting point of block erection.

☑ At this time, put several supports under the ship for supporting ship's weight

Support

Erection

Block Erection Simulation Considering Semi-tandem Construction Method





Semi-tandem Construction Method

➡ Construct a complete ship and another ship's after body together in the dock



* **Myung-Il Roh**, Kyu-Yeul Lee, "An Initial Hull Structural Modeling System for Computer-Aided Process Planning in Shipbuilding", Advances in Engineering Software, Vol. 37, No. 7, pp.457-476, 2006.7





Launching (L/C)

Launching (L/C)



- ☑ Process for that is dry in the dock or on the ground for the first time after various tests
- ☑ The date is about 12 months before contract date.

* Reference: DSME

Launching
- Ground Launching Method of HHI and S...



- ☑ Building a ship on land rather than a dock
- ☑ In October 2004, Hyundai Heavy Industries was the first in the world to succeed.
- ☑ Overall procedures of ground launching method
  1. Complete the erection of a ship on land
  2. Two barges are placed next to the land area.
  3. The ship is pulled over the barge ("Load Out") using the principle of submarine in Germany and the principle of mobile system developed by Switzerland
  4. Move a barge carrying the ship to the deep sea
  5. The barge sinks below the surface of the water.
  6. Finish launching of the ship

* Reference: Hyundai Heavy Industries

Quay Work

Quay Work
- Outfitting/Painting



☑ After launching the ship, put her on the quay and

.

Quay Work
- Sea Trial



for conducting to measure her performance and general seaworthiness.

- ☑ It is usually the last phase of construction and takes place on open water, and it can last from a few hours to many days.
- ☑ The ship's speed, maneuverability, equipment, and safety features are usually conducted.
- ☑ Typical trials: speed trial, crash stop, endurance, maneuvering trials, seakeeping

Delivery (D/L)

Delivery (D/L)
- Naming Ceremony and Delivery



to a

ship owner

Naming Ceremony of FPSO (Floating Production Storage Off-loading)