Lecture Note of Innovative Ship and Offshore Plant Design

Innovative Ship and Offshore Plant Design Part I. Ship Design

Ch. 4 Deadweight Carrier and Volume Carrier

Spring 2018

Myung-Il Roh

Department of Naval Architecture and Ocean Engineering Seoul National University

novative Ship and Offshore Plant Design, Spring 2018, Myung-II Roh

rydlab 1

Contents

- ☑ Ch. 1 Introduction to Ship Design
- ☑ Ch. 2 Design Equations
- ☑ Ch. 3 Design Model
- ☑ Ch. 4 Deadweight Carrier and Volume Carrier
- ☑ Ch. 5 Freeboard Calculation
- ☑ Ch. 6 Resistance Prediction
- ☑ Ch. 7 Propeller and Main Engine Selection
- ☑ Ch. 8 Hull Form Design
- ☑ Ch. 9 General Arrangement (G/A) Design
- ☑ Ch. 10 Structural Design
- ☑ Ch. 11 Outfitting Design

ovative Ship and Offshore Plant Design, Spring 2018, Myung-Il Roh

Ch. 4 Deadweight Carrier and Volume Carrier

- 1. Characteristics of Deadweight Carrier and Volume
- 2. Procedures of the Determination of Principal Dimensions for Deadweight Carrier and Volume Carrier
- 3. Examples of Determination of the Principal Dimensions of Deadweight Carrier and Volume Carrier

novative Ship and Offshore Plant Design, Spring 2018, Myung-Il Rob

rydlab 3

1. Characteristics of Deadweight Carrier and Volume Carrier

novative Ship and Offshore Plant Design, Spring 2018, Myung-II Roh

rydlab 4

Deadweight Carrier vs. Volume Carrier

is a ship whose is a critical factor when the cargo to be carried is "heavy" in relation to the space provided for it.

The ship will be **weight critical** when the ship carries a cargo which has a density greater than α or inversely lesser than 1.29 m³/ton.

For an example, an ore carrier loads the iron ore (density ≈ 7.85 ton/m³) in alternate holds, "alternated loading", therefore this kind of ship needs less than a half of the hold volume.

**Approximate formula of roll periods (τ .)



<Alternated loading in ore carrier>

is a ship whose cargo to be carried is "provided for it.

Ship and Offshore Plant Design, Spring 2018, Myung-II Roh

is a critical factor when the " in relation to the space

Membrane-type LNG

 $T_r = \frac{2k \cdot B}{\sqrt{GM}}$ $GM: \mbox{Metacentric height}$

B: Breadth, k: 0.32~0.39 for full loading 0.37~0.40 for ballast condition

rudlab

Examples of Volume Carriers

Containers are arranged in bays in lengthwise, rows in beam wise, tiers in depth wise.

Therefore, length, breadth and depth of a container carrier vary according to the number and size of containers.





Moreover, container carrier loads containers on deck, and that causes to be the ultimate criterion.


Cruise ship is a kind of **volume carrier** because it has **many decks and larger space for passengers.**And the which becomes the critical criterion on cruise ship.



ovative Ship and Offshore Plant Design, Spring 2018, Myung-Il Roh












2. Procedures of the Determination of Principal Dimensions for Deadweight Carrier and Volume Carrier

Procedure of the Determination of Principal Dimensions for a Deadweight Carrier At first, the principal **Weight Equation (Physical Constraint)** dimensions such as L, B, T, $\rho \cdot L \cdot B \cdot T \cdot C_B \cdot (1 + \alpha) = DWT + LWT$ C_B are determined according ✓ Given: DWT (owner's requirements) to the ✓ Find: L, B, T, C_B **Volume Equation (Economical Constraints)** Next, the depth is determined considering the $V_{CH} = f(L, B, D)$ required cargo hold capacity ✓ Given: L, B, V_{CH} (owner's requirements) according to the ✓ Find: D Freeboard Calculation (Regulatory Constraints) •Then, it should be checked <u>lastly</u> that whether the $D \ge T + Fb(L, B, D, C_{\scriptscriptstyle R})$ depth and draft satisfy the 3 \checkmark Given: L, B, D, T, C_B ✓ Check: Whether the chosen depth is equal or greater than the draft plus required freeboard or not. sydlab 13



3. Examples of Determination of the Principal Dimensions of Deadweight Carrier and Volume Carrier

ydlab 15

Determination of the Principal Dimensions of a 297,000 ton Deadweight VLCC based on a 279,500 ton Deadweight VLCC (Deadweight Carrier)

Jydlab 16

Example of the Principal Particulars of the Basis Ship of 279,500 ton Deadweight VLCC and Owner's Requirements of the Design Ship of 297,000 ton Deadweight VLCC Design Ship: 297,000 Ton Deadweight VLCC (Very Large Crude oil Carrier) Basis Ship Owner's Requirements • Dimensional Ratios abt. 330.30 m L/B = 5.41, Lbp B,mld 314.00 m $B/T_d = 2.77$, 58.00 m Principal Depth,mld 31.00 m B/D = 1.87, Td(design) 20.90 m 21.50 m L/D = 10.1222.20 m Ts(scant.) 22.84 m 301,000 ton Hull Form Coefficient Deadweight (scant) Deadweight (design) 279,500 ton 297,000 ton $C_{B-d} = 0.82$ Speed (at design draft 15.0 knots 16.0 knots • Lightweight (=41,000 ton) 90% MCR (with 15% Sea Margin) - Structural weight B&W 7S80MC ≈ 36,400 ton (88%) 32,000 PS x 74.0 RPM MCR - Outfit weight 28,800 PS x 71.4 RPM NCR $\approx 2,700 \text{ ton } (6.6\%)$ SFOC 122.1 g/BHP·h ö - Machinery weight DFOC 84.4 ton/day Based on NCR $\approx 1,900 \text{ ton } (4.5\%)$ $\text{density} = \frac{\text{Deadweight}_{\text{see}}}{\text{Deadweight}_{\text{see}}}$ Cruising Range 26 000 N/M 26 500 N/M Double side Double side Cargo density = Shape of Midship Section / Double bottom / Double bottom Cargo hold capacity Cargo Hold abt. 345,500 m³ abt. 360,000 m³ 301,000 H.F.O. abt. 7.350 m³ 345.500 D.O. abt. 490 m³ $= 0.87 [ton/m^3] > 0.77$ Fresh Water abt. 460 m³ Including Peak **Deadweight Carrier** sydlab 17

Determination of the Principal Dimensions of 297,000 ton Deadweight VLCC Step 1: Weight Equation

Step 1: Weight Equation

Step 1: The principal dimensions such as L, B, T_d , and $C_{B,d}$ are determined by the $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT_d \cdot C_{B,d} \cdot (1+\alpha)$ $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot C_{B,d} \cdot (1+\alpha)$ $\rho \cdot L \cdot B$

Step 1: Weight Equation - Method 2 for the Total Weight Estimation (1/4) Step 2: Step 3: Freeboard Calculation

 $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ Given: $DWT_d = 297,000 [ton], T_d = 21.5[m]$ Find: $L, B, C_{B,d}$

Method 2: Assume that the total weight (W) is proportional to the deadweight. $W = \frac{W_{Basis}}{DWT_{d,Basis}} \cdot DWT_{d}$ $L \cdot B \cdot T_{d} \cdot C_{B,d} \cdot \rho \cdot (1+\alpha) = W$

$$W = \frac{W_{Basis}}{DWT_{d Basis}} \cdot DWT_{d}$$

$$L \cdot B \cdot T_d \cdot C_{Bd} \cdot \rho \cdot (1+\alpha) = W$$

Design ship and basis ship are assumed to have the same ratio of the deadweight to the total weight.

Therefore, the total weight of the design ship can be estimated by the ratio of the deadweight to the total weight of the basis ship.

$$\frac{DWT_{d,Basis}}{W_{Basis}} = \frac{DWT_d}{W} \qquad \Longrightarrow \qquad W = \frac{W_{Basis}}{DWT_{d,Basis}} \cdot DWT_d$$

$$= \frac{320,500}{279,500} \cdot 297,000$$

$$= 340,567 \ [ton]$$

sydlab 19

Step 1: Weight Equation - Method 2 for the Total Weight Estimation (2/4)

Step 3:

Freeboard $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$ Given: $DWT_d = 297,000 [ton], T_d = 21.5[m]$ Find: $L, B, C_{B,d}$

$$L \cdot B \cdot T_d \cdot C_{B,d} \cdot \rho \cdot (1+\alpha) = W$$

$$L \cdot B \cdot 21.5 \cdot C_{B,d} \cdot 1.025 \cdot (1 + 0.002) = 340,567$$

$$L \cdot B \cdot C_{B,d} \cdot 22.08 = 340,567 \cdots (5.2)$$

There are 3 unknown variables (L, B, $C_{B,d}$) with one given equation.

Therefore, we have to assume two variables to solve this indeterminate equation.

The values of the dimensional ratio L/B and $C_{B,d}$ can be obtained from the basis ship.

$$L/B = L_{Basis}/B_{Basis}$$
 $C_{B,d} = C_{B,d,Basis} = 0.8213$
= 314/58
= 5.413

ative Ship and Offshore Plant Design, Spring 2018, Myung-II Roh

Substituting the ratio obtained from the basis ship into the equation (5.2), the equation can be converted to a quadratic equation in L.

$$L \cdot (L/(L/B)) \cdot C_{B,d} \cdot 22.08 = 340,567$$


$$L(L/5.143) \cdot 0.8213 \cdot 22.08 = 340,567$$

$$L^{2} \cdot 3.349 = 340,567$$

$$\therefore L = 318.85[m]$$

anovative Ship and Offshore Plant Design Spring 2018 Myung-II Ro

sydlab 21



We can obtain B from the ratio L/B of the basis ship.

$$B = L/(L/B)$$

= 318.85/5.413
= 58.90 [m]
 $\therefore L = 318.85[m], B = 58.90[m], C_{B,d} = 0.8213$

Then, the is determined considering the required cargo hold capacity by .

And it should be checked lastly that whether the

ovative Ship and Offshore Plant Design, Spring 2018, Myung-Il Roh

Determination of the Principal Dimensions of 297,000 ton Deadweight VLCC

- Step 2: Volume Equation (1/2)



Step 2: Next, the depth is determined considering the required cargo hold capacity by the

$$V_{CH} = f(L, B, D)$$

✓ Given: L = 318.85[m], B = 58.90[m], $V_{CH} = 360,000[m^3]$

✓ Find: D

sydlab 23

Determination of the Principal Dimensions of 29 Step 1: Weight

- Step 2: Volume Equation (2/2)



 $V_{\scriptscriptstyle CH} = f(L,B,D)$ Given: L=318.85[m], B=58.90[m], V_{CH} = 360,000[m³] Find: D

Assume that the <u>cargo hold capacity</u> is proportional to $\underline{L \cdot B \cdot D}$.

$$f(L,B,D) = C_{CH} \cdot L \cdot B \cdot D$$

$$V_{CH} = C_{CH} \cdot L \cdot B \cdot D$$

The coefficient C_{CH} can be obtained from the basis ship.

$$C_{CH} = \frac{V_{CH}}{L \cdot B \cdot D} \bigg|_{Basis} = \frac{345,500}{314 \cdot 58 \cdot 31} = 0.612$$

We use the same coefficient $\mathcal{C}_{\mathit{CH}}$ for the determination of depth.

$$V_{CH} = C_{CH} \cdot L \cdot B \cdot D$$

 $360,000 = 0.612 \times 318.85 \times 58.90 \times D$

$$D = 31.32[m]$$

ative Ship and Offshore Plant Design, Spring 2018, Myung-II Roh


Determination of the Principal Dimensions of 297,000 ton Deadweight VLCC

- Step 3: Freeboard Calculation (1/2)

Weight Equation Step 2: Volume Equation Step 3: Freeboard

Step 3: Then, it should be checked whether the depth and draft satisfy the freeboard regulation.

$$D_{Fb} \geq T_s + Fb(L, B, D_{mld}, C_{B,d})$$



✓ Given: L = 318.85[m], B = 58.90[m], $D (=D_{mld}) = 31.32[m]$, $T_{s.Rea.} = 22.84[m]$, $C_{B.d.Basis} = 0.8213$, $t_{stringer,Basis} = 0.02[m]$

✓ Check: The freeboard of the ship should be larger than the required freeboard.

nnovative Ship and Offshore Plant Design, Spring 2018, Myung-II Roh

JUILO 25

Determination of the Principal Dimensions of 29 st

- Step 3: Freeboard Calculation (2/2)

rep 1: Step 2: Volume Equation Step 5: Calculation

At the early design stage, there are few data available for estimation of required freeboard. Thus, the required freeboard can be estimated from the basis ship.

$$\begin{split} D_{Fb} \geq T_s + Fb(L,B,D_{mld},C_{B,d}) \\ \text{Given: } L=&318.85[m], B=&58.90[m], D \; (=D_{mld})=&31.32[m], \\ T_s=&2.84[m], C_{B_s}=&0.8213, \underbrace{1_{s_{B_s}}}_{1_{s_{B_s}}}=&0.02[m] \\ \text{Check: Freeboard of the ship should be larger than that in accordance with the freeboard regulation.} \end{split}$$

Assume that the freeboard is proportional to the depth.

$$Fb(L, B, D_{mld}, C_{B,d}) = C_{Fb} \cdot D_{mld}$$

$$D_{Fb} \ge T_s + C_{Fb} \cdot D_{mld}$$

The coefficient C_{Fb} can be obtained from the basis ship.

$$C_{Fb} = \frac{Fb}{D_{mld}}\Big|_{D_{mld}} = \frac{7.84}{31} = 0.253$$

Check: Freeboard of the design ship

$$D_{Fb} \ge T_s + C_{Fb} \cdot D_{mld}$$

$$D_{mld} + t_{stringer} \ge T_s + C_{Fb} \cdot D_{mld}$$

$$31.32 + 0.02 \ge 22.84 + 0.253 \cdot 31.32$$

 $31.34 \ge 30.76$: Satisfied

It is satisfied. However, this method is used for a rough estimation. Thus, <u>after</u> the principal dimensions are determined more accurately, <u>freeboard needs to be calculated more accurately in accordance with ICLL 1966</u>.

Step 1: Weight Equation
- Method 3 for the Lightweight Estimation (1/3)

Step 1:
Weight Equation Step 2: Step 3: Freeboard Calculation

 $\begin{array}{l} \rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + \begin{tabular}{c} LWT\\ \hline \text{Given: } DWT_d = 297,000 \ [ton], \ T_d = 21.5[m]\\ \hline \text{Find:} \quad L, B, C_{B,d} \end{array}$

<u>Method 3</u>: Assume that the lightweight could vary as the volume of the vessel represented by $\underline{L\cdot B\cdot D}$. $LWT = C_{LWT}L\cdot B\cdot D$

$$L \cdot B \cdot T_d \cdot C_{B,d} \cdot \rho \cdot (1 + \alpha) = DWT_d + C_{LWT} \cdot L \cdot B \cdot D$$

The coefficient C_{LWT} can be obtained from the basis ship.

$$C_{LWT} = \frac{LWT}{L \cdot B \cdot D} \bigg|_{Basis} = \frac{41,000}{314 \cdot 58 \cdot 31} = 0.072$$

$$L \cdot B \cdot T_d \cdot C_{B,d} \cdot \rho \cdot (1+\alpha) = DWT_d + C_{LWT} \cdot L \cdot B \cdot D$$

$$L \cdot B \cdot 21.5 \cdot C_{B,d} \cdot 1.025 \cdot (1+0.002) = 297,000 + 0.072 \cdot L \cdot B \cdot D$$

$$L \cdot B \cdot C_{B,d} \cdot 22.08 = 297,000 + 0.072 \cdot L \cdot B \cdot D \cdots (5.3)$$

There are 4 unknown variables (L, B, D, $C_{B,d}$) with one given equation.

▶ Nonlinear indeterminate equation!

nnovative Ship and Offshore Plant Design, Spring 2018, Myung-Il Roh

sydlab 27

Step 1: Weight Equation - Method 3 for the Lightweight Estimation (2/3)

weight Equation Volume Equation Calculation $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + \frac{1}{2} \frac{1$

Method 3: $LWT = C_{LWT}L \cdot B \cdot D$

 $L \cdot B \cdot C_{B,d} \cdot 22.08 = 297,000 + 0.072 \cdot L \cdot B \cdot D \cdots (5.3)$

Therefore, we <u>have to assume</u> three variables to solve this indeterminate equation.

The values of the dimensional ratios L/B, B/D and $C_{B,d}$ can be obtained from the basis ship.

$$L/B = L_{Basis}/B_{Basis}$$
 $B/D = B_{Basis}/D_{Basis}$ $C_{B,d} = C_{B,d,Basis} = 0.8213$
= 314/58 = 58/31
= 5.413 = 1.871

Substituting the ratios obtained from the basis ship into the equation (5.3), the equation can be converted to a cubic equation in L.

$$L \cdot \left(L / \left(L / B \right) \right) \cdot C_{B,d} \cdot 22.08 = 297,000 + 0.072 \cdot L \cdot \left(L / \left(L / B \right) \right) \cdot \left(L / \left(L / B \right) / \left(B / D \right) \right)$$

ovative Ship and Offshore Plant Design, Spring 2018, Myung-Il Rol

Step 1: Weight Equation

- Method 3 for the Lightweight Estimation (3/3)

$$L \cdot (L/(L/B)) \cdot C_{B,d} \cdot 22.08 = 297,000 + 0.072 \cdot L \cdot (L/(L/B)) \cdot (L/(L/B)/(B/D))$$

$$L(L/5.143) \cdot 0.8213 \cdot 22.08 = 297,000 + 0.072 \cdot L \cdot (L/5.413) \cdot ((L/5.413)/1.871)$$

$$L^2 \cdot 3.349 = 297,000 + L^3 \cdot 0.0013$$

$$L = 318.48 [m]$$

Then B is calculated from the ratio L/B of the basis ship.

$$B = L/(L/B)$$

= 318.48/5.413
= 58.82[m] $\therefore L = 318.48[m], B = 58.82[m], C_{B,d} = 0.8213$


Then, the is determined considering the required cargo hold capacity by .

And it should be checked lastly whether the <u>depth and draft satisfy</u> <u>the freeboard regulation</u>.

annuative Chin and Offshare Plant Design Engine 2019 Marine II Bo

ydlab 29

Step 1: Weight Equation
- Method 4 for the Lightweight Estimation in Components (1/7)



 $\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1 + \alpha) = DWT_d + \frac{1}{2} \underbrace{WWT}_{b}$ Given: $DWT_d = 297,000 \ [ton], \ T_d = 21.5[m], \ V_S = 16 \ [knots]$ Find: $L, B, C_{B,d}$

Method 4: Estimate the

$$LWT = W_s + W_o + W_m$$

$$L \cdot B \cdot T_d \cdot C_{B,d} \cdot \rho \cdot (1+\alpha) = DWT_d + W_s + W_o + W_m$$

(W_s) is estimated as follows:


$$W_s = C_s \cdot L^{1.6} \cdot (B+D)$$


The coefficient C_s can be obtained from the basis ship.


$$C_s = \frac{W_s}{L^{1.6} \cdot (B+D)} \bigg|_{Basis} = \frac{36,400}{314^{1.6} \cdot (58+31)} = 0.0414$$

novative Ship and Offshore Plant Design, Spring 2018, Myung-Il Roh


sydlab so









Step 1: Weight Equation - Method 4 for the Lightweight Estimation in Components (5/7) $L \cdot B \cdot 21.5 \cdot C_{B,d} \cdot 1.025 \cdot (1 + 0.002) = 297,000 + 0.0414 \cdot L^{1.6} \cdot (B + D) + 0.1483 \cdot L \cdot B$ $+0.0514 \cdot (0.0022 \cdot (L \cdot B \cdot 21.5 \cdot C_{B,d} \cdot 1.025 \cdot (1+0.002))^{2/3} \cdot 16^3)$ $L \cdot B \cdot C_{Bd} \cdot 22.08 = 297,000 + 0.0414 \cdot L^{1.6} \cdot (B+D) + 0.1483 \cdot L \cdot B$ $+0.00012\cdot(L\cdot B\cdot C_{_{B,d}}\cdot 22.08)^{^{2/3}}\cdot 16^{^3}\cdots (5.4)$ There are 4 unknown variables (L, B, D, $C_{B,d}$) with one equation. **▶** Nonlinear indeterminate equation! Therefore, we have to assume three variables to solve this indeterminate equation. The values of the dimensional ratios L/B, B/D, and $C_{B,d}$ can be obtained from the basis ship. $L/B = L_{Basis}/B_{Basis}$ $B/D = B_{Basis}/D_{Basis}$ $C_{B.d} = C_{B.d.Basis} = 0.8213$ =314/58= 58/31= 5.413=1.871sydlab 34 ative Ship and Offshore Plant Design, Spring 2018, Myung-II Roh





Determination of Principal Dimensions of a 160,000 m³ LNG Carrier based on a 138,000 m³ LNG Carrier (Volume Carrier)

novative Ship and Offshore Plant Design, Spring 2018, Myung-II Roh



Determination of the Principal Dimensions of 160,000 m³ LNG Carrier

- Step 1: Volume Equation (1/4)

Step 1: Volume Equation

Step 2: Weight Equation Step 3: Freeboard Calculation

Step 1: The principal dimensions such as L, B, D are determined considering the required cargo hold capacity by the .

$$V_{CH} = f(L, B, D)$$

✓ **Given:** $V_{CH} = 160,000[m^3]$


✓ Find: *L, B, D*

novative Ship and Offshore Plant Design, Spring 2018, Myung-Il Rob

JUDIO 39

Determination of the Principal Dimensions (Step 1: Volume Fountier (2/4)

- Step 1: Volume Equation (2/4)



Given: $V_{CH} = 160,000[m^3]$ Find: L, B, D

Assume that the <u>cargo hold capacity</u> is proportional to $\underline{L \cdot B \cdot D}$.

$$f(L,B,D) = C_{CH} \cdot L \cdot B \cdot D$$

$$V_{CH} = C_{CH} \cdot L \cdot B \cdot D$$

Coefficient C_{CH} can be obtained from the basis ship.

$$C_{CH} = \frac{V_{CH}}{L \cdot B \cdot D} \bigg|_{Basis} = \frac{138,000}{266 \cdot 43.4 \cdot 26} = 0.460$$

$$V_{CH} = C_{CH} \cdot L \cdot B \cdot D$$

$$160,000 = 0.460 \cdot L \cdot B \cdot D \cdots (6.1)$$

There are 3 unknown variables (L, B, D) with one equation.

▶ Nonlinear indeterminate equation!

novative Ship and Offshore Plant Design, Spring 2018, Myung-Il Ro

Determination of the Principal Dimensions - Step 1: Volume Equation (3/4)



 $160,000 = 0.460 \cdot L \cdot B \cdot D \cdots (6.1)$

 $V_{CH} = f(L,B,D)$ Given: $V_{CH} = 160,000[m^2]$ Find: L,B,D $f(L,B,D) = C_{CH} \cdot L \cdot B \cdot D$

Therefore, we <u>have to assume</u> two variables to solve this indeterminate equation.

The values of the dimensional ratios L/B and B/D can be obtained from the basis ship.

$$L/B = L_{Basis} / B_{Basis}$$
 $B/D = B_{Basis} / D_{Basis}$
= 266 / 43.4 = 43.4 / 26
= 6.129 = 1.670

Substituting the ratios obtained from basis ship into the equation (6.1), the equation can be converted to a cubic equation in L.

$$160,000 = 0.460 \cdot L \cdot (L/(L/B)) \cdot (L/(L/B)/(B/D))$$

$$160,000 = 0.460 \cdot L \cdot (L/6.129) \cdot (L/6.129/1.670)$$

$$160,000 = 0.007 \cdot L^{3}$$

L = 279.4[m]

nnovative Ship and Offshore Plant Design, Spring 2018, Myung-II Rol

sydlab 41

Determination of the Principal Dimensions of 160,000 m³ LNG Carrier - Step 1: Volume Equation (4/4)

L = 279.4 [m]

We can obtain B and D from the ratios L/B and B/D of the basis ship.

$$B = L/(L/B)$$
 $D = L/(L/B)/(B/D)$
= 279.4/6.129 = 279.4/6.129/1.669
= 27.3 [m]

$$\therefore L = 279.4[m], \quad B = 45.6[m], \quad D = 27.3[m]$$

ovative Ship and Offshore Plant Design, Spring 2018, Myung-Il Roh

Determination of the Principal Dimensions of 160,000 m³ LNG Carrier

- Step 2: Weight Equation





Step 3: Freeboard Calculation

Step 2: Then, block coefficient ($C_{B,d}$) is determined by the

$$\rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT$$

 ρ : density of sea water = 1.025 ton/m³ α : a fraction of the shell appendage allowance = 0.002

✓ Given:
$$L = 279.4[m]$$
, $B = 45.6[m]$, $D = 27.3[m]$, $T_d = 11.4[m]$, $DWT_d = 80,000[ton]$, $V_s = 19.5[knots]$

✓ Find: $C_{B,d}$

*Subscript d: at design draft

JUGIO 43

novative Ship and Offshore Plant Design, Spring 2018, Myung-Il Rob

Step 2: Weight Equation
- Method 4 for the Lightweight Estimation in Components (1/5)

Step 1:
Volume
Equation

Step 2:
Weight
Equation

Step 3:
Freeboard
Calculation

 $\begin{array}{l} \rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + \overline{LWT}; \\ \textbf{Given: } L = 279.4[m], B = 45.6[m], D = 27.3[m], T_d = 11.4[m], \\ DWT_d = 80.000[ton], V = 19.5[knots] \\ \hline \text{Find: } C_{-1}, \end{array}$

Method 4: Estimate the structural weight (W_s) , outfit weight (W_o) , and machinery weight (W_m) in components.

$$LWT = W_s + W_o + W_m$$

$$L \cdot B \cdot T_d \cdot C_{B,d} \cdot \rho \cdot (1+\alpha) = DWT_d + W_s + W_o + W_m$$


Structural weight (W_s) is estimated as follows:


$$W_s = C_s \cdot L^{1.6} \cdot (B+D)$$


The coefficient C_s can be obtained from the basis ship.


$$C_s = \frac{W_s}{L^{1.6} \cdot (B+D)} \bigg|_{Basis} = \frac{21,600}{266^{1.6} \cdot (43.4+26)} = 0.0410$$

ovative Ship and Offshore Plant Design, Spring 2018, Myung-II Rob









Determination of the Principal Dimensions of 160,000 m³ LNG Carrier


- Step 3: Freeboard Calculation (1/2)





Step 3: Then, it should be checked lastly whether the depth and draft satisfy the freeboard regulation.

$$D_{Fb} \geq T_s + Fb(L, B, D_{mld}, C_{B,d})$$



✓ Given:
$$L$$
=279.4[m], B =45.6[m], D (= D_{mld})=27.3[m], T_s = 12.1[m], $C_{B,d}$ =0.773, $t_{stringer}$ =0.02[m]

Check: The freeboard of the ship should be larger than the required freeboard.

sydlab 49

Determination of the Principal Dimensions (

- Step 3: Freeboard Calculation (2/2)

$$\begin{split} &D_{Fb} \geq T_s + Fb(L,B,D_{mld},C_{B,d})\\ &L = 279.4 \text{[m]}, B = 45.6 \text{[m]}, D(=D_{mld}) = 27.3 \text{[m]},\\ &T_s = 12.1 \text{[m]}, C_{B,d} = 0.773, t_{stringer} = 0.02 \text{[m]} \end{split}$$

At the early design stage, there are few data available for estimation of required freeboard. Thus, the required freeboard can be estimated from the basis ship.

c: Freeboard of the ship should be larger than that in accordance with the freeboard regulation.

Assume that the freeboard is proportional to the depth.

$$Fb(L, B, D_{mld}, C_{B,d}) = C_{Fb} \cdot D_{mld}$$

$$D_{Fb} \ge T_s + C_{Fb} \cdot D_{mld}$$

The coefficient
$$C_{Fb}$$
 can be obtained from the basis ship.
$$C_{Fb} = \frac{Fb}{D_{mld}}\bigg|_{Basis} = \frac{6.68}{26} = 0.257$$

Check: Freeboard of the design ship

$$\begin{split} D_{Fb} &\geq T_s + C_{Fb} \cdot D_{mld} \\ D_{mld} + t_{stringer} &\geq T_s + C_{Fb} \cdot D_{mld} \\ 27.3 + 0.02 &\geq 12.1 + 0.257 \cdot 27.3 \\ 27.32 &\geq 19.11 : \text{Satisfied} \end{split}$$


It is satisfied. However, this method is used for a rough estimation. So, after the main dimensions are determined more accurately, freeboard needs to be calculated more accurately through the freeboard regulation.


Determination of Principal Dimensions of a 4,100 TEU Container Carrier based on a 3,700 TEU Container Carrier (Volume Carrier)


novative Ship and Offshore Plant Design, Spring 2018, Myung-Il Rob


JUGLAND 51

Design Ship: 4,100 TEU Container Carrier			
	Basis Ship	Owner's requirements	Basis Ship Dimensional Ratios
Principal Dimensions LOA LBP	257.4 m 245.24 m	less than 260.0 m	L/B = 7.62 $B/T_d = 3.19$
Bmld Dmld	32.2 m 19.3 m	less than 32.25 m	B/D=1.67
Td /Ts (design / scant)	10.1 / 12.5 m	abt. 11.0 / 12.6 m	L/D = 12.71 • Hull Form Coefficient
Deadweight (design / scant)	34,400 / 50,200 ton	40,050 / 49,000 ~ 51,000 ton	$C_{B} = 0.62$
Capacity			• Lightweight (=16,000 to
Container on Deck / in Hold	2,174 TEU / 1,565 TEU	abt. 4,100 TEU	- Structural weight $\approx 11,000 \text{ ton } (\approx 68\%)$ - Outfit weight $\approx 3,200 \text{ ton } (\approx 20\%)$ - Machinery weight $\approx 1,800 \text{ ton } (\approx 12\%)$ Cargo density = $\frac{\text{Deadweight}_{\text{card}}}{\text{Cargo hold capacit}}$ = $\frac{\text{Deadweight}_{\text{container}} \times N_{\text{container}}}{V_{\text{container}}}$ = $\frac{50,200}{46.9 \cdot 3,739}$
Ballast Water Heavy Fuel Oil	13,800 m ³ 6,200 m ³	abt. 11,500 m ³	
Main Engine & Speed M/E Type MCR (BHP × rpm) NCR (BHP × rpm) Service Speed at NCR (Td, 15% SM) DFOC at NCR Cruising Range	Sulzer 7RTA84C 38,570 BHP × 102 RPM 34,710 BHP × 8.5 RPM 22.5 knots (at 11.5 m) at 30,185 BHP 103.2 ton 20,000 N/M	24.5 knots (at 11.0 m) abt. 20,000 N/M	









Determination of the Principal Dimensions of 4,100 TEU Container Carrier
- Step 1: Volume Equation (1/11)

Step 2: Step 3:

Step 1: The length, breadth, and depth of container carrier are determined to a great extent

$$N_{C_{_req}} = f(N_L, N_B, N_D)$$

- ✓ Given: The number of containers to be required = 4,100 [TEU]
- \checkmark Find: N_L , N_B , N_D


novative Ship and Offshore Plant Design, Spring 2018, Myung-Il Rob

sydlab 57

Determination of the Principal Dimensions of 4,100 TEU Container Carrier - Step 1: Volume Equation (2/11)

1. The number of additional containers to satisfy owner's requirement (4,100 *TEU*)


Basis ship (3,700 TEU Container Carrier)




In Hold: 1,565 *TEU*On Deck: 2,174 *TEU*Total: 3,739 *TEU*

→ The number of additional containers to be required: 361 *TEU* (= 4,100 – 3,739 *TEU*)

ovative Ship and Offshore Plant Design, Spring 2018, Myung-Il Roh






Determination of the Principal Dimensions of 4,100 TEU Container Carrier - Step 1: Volume Equation (5/11)

2) Available length of the design ship

$$\begin{split} L_{crane} &= (L_{space\ of\ crane} - L_{lashing\ bridge}) \cdot N_{space\ of\ crane} \\ &= (3.4 - 1.6) \cdot 3 \\ &= 5.4[m] \end{split}$$



 L_{crain} : Available length of design ship by utilizing the space of crane $L_{space of crain}$: Crane and available space $L_{tashing craing}$: Space of lashing bridge (= Clearance between cargo holds, $L_{clear,hold}$) $N_{space of craine}$: Number of crane and available space

3) Total available length of design ship in lengthwise

$$=L_{OA,available}+L_{crane}$$
$$=2.6+5.4$$


$$= 2.0 + 3.4$$


 $=8[m]>7.14[m]\rightarrow$ It is possible to increase 1 bay in hold.


$$N_L = N_{L,basis} + 1 = 26 + 1$$


= 27 [Bays]


nnovative Ship and Offshore Plant Design, Spring 2018, Myung-II Ro











Determination of the Principal Dimensions of 4,100 TEU Container Carrier - Step 1: Volume Equation (11/11)

5. Principal dimensions (L, B, D) determined by the arrangement of containers in cargo hold (N_L , N_D , N_B):

$$N_L = 27 \text{ [Bays]}$$
 $N_B = 11 \text{ [Rows]}$ $N_D = 7 \text{ [Tiers]}$ $L = 7.14 \cdot N_L + 54.52$ $B = 2.523 \cdot N_B + 4.447$ $D = 2.604 \cdot N_D + 1.072$ $= 7.14 \cdot 27 + 54.52$ $= 2.523 \cdot 11 + 4.447$ $= 2.604 \cdot 7 + 1.072$ $= 247.76[m]$ $= 32.2[m]$ $= 19.3[m]$

$$\therefore L = 247.76[m], \qquad B = 32.2[m], \qquad D = 19.3[m]$$

novative Ship and Offshore Plant Design, Spring 2018, Myung-Il Rob

sydlab 67

Determination of the Principal Dimensions of 4,100 TEU Container Carrier

- Step 2: Weight Equation

Step 1: Volume

Step 2: Weight

Step 3: Freeboard

Step 2: Then, block coefficient ($C_{B,d}$) is determined by the

$$\boxed{ \rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT} \\ \text{ $_{\rho$. density of sea water = 1.025 ton/m}^3$} \\ \text{ $_{\alpha$: a fraction of the shell appendage allowance}$} \\ = 0.0029 \\ \left(1 + \alpha = \frac{Displacement}{Moulded\ Displaced\ Volume} \bigg|_{basis} = \frac{49,848.7}{49,652.7} = 1.0039 \right)$$

✓ Given: L = 247.76[m], B = 32.2[m], D = 19.3[m], $T_d = 11.0[m]$, $DWT_d = 40,050[ton]$, $V_s = 24.5[knots]$

✓ Find: $C_{B,d}$

*Subscript d: at design draft

novative Ship and Offshore Plant Design, Spring 2018, Myung-II Roh

sydlab 📾

Step 2: Weight Estimation Method 4 for the Lightweight Estimation in Components (1/5)

Step 3:

Freeboard Step 2:
Weight
Equation Step 1: Volume Calculation

 $\begin{array}{l} \rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + \underline{LWT} \\ \text{Given: } L = 247.76[m], B = 32.2[m], D = 19.3[m], T_d = 11.0[m], \\ DWT_d = 40.050[ton], V = 24.5[knots] \\ \end{array}$

Method 4: Estimate the structural weight (W), outfit weight (Wo), and machinery weight (W_m) in components.

$$LWT = W_s + W_o + W_r$$

$$LWT = W_s + W_o + W_m$$

$$L \cdot B \cdot T_d \cdot C_{B,d} \cdot \rho \cdot (1+\alpha) = DWT_d + W_s + W_o + W_m$$

Structural weight (W_s) is estimated as follows:

$$W_{s} = C_{s} \cdot L^{1.6} \cdot (B+D)$$

The coefficient C_s can be obtained from the basis ship.

$$C_s = \frac{W_s}{L^{1.6} \cdot (B+D)} \Big|_{Basis} = \frac{11,000}{245.24^{1.6} \cdot (32.2+19.3)} = 0.032$$

ve Ship and Offshore Plant Design, Spring 2018, Myung-Il Roh

sydlab ...

Step 2: Weight Estimation Method 4 for the Lightweight Estimation in Components (2/5)

Step 3:
Freeboard
Calculation $\begin{array}{l} \rho \cdot L \cdot B \cdot T_d \cdot C_{B,d} \cdot (1+\alpha) = DWT_d + LWT \\ \text{Given: } L = 247.76[m], B = 32.2[m], D = 19.3[m], T_d = 11.0[m], \\ DWT_d = 40,050[ton], V = 24.5[knots] \end{array}$

Method 4: $LWT = W_s + W_o + W_n$

Outfit weight (W_o) is estimated as follows:

$$W_o = C_o \cdot L \cdot B$$

The coefficient C_o can be obtained from the basis ship.


$$C_o = \frac{W_o}{L \cdot B} \bigg|_{Basis} = \frac{3,200}{245.24 \cdot 32.2} = 0.405$$

Machinery weight (W_m) is estimated as follows:

$$W_m = C_m \cdot NMCR$$

The coefficient C_m can be obtained from the basis ship.


$$C_m = \frac{W_m}{NMCR}\Big|_{Basis} = \frac{1,800}{38,570} = 0.047$$





Main engine of basis ship


At the early design stage, NMCR can be estimated by 'Admiralty formula'.

ative Ship and Offshore Plant Design, Spring 2018, Myung-Il Roh










Definition of Freeboard Deck

Freeboard Deck (D_d)¹⁾:

- (a) The freeboard deck is normally the uppermost complete deck exposed to weather and sea, which has permanent means of closing all openings in the weather part thereof, and below which all openings in the sides of the ship are fitted with permanent means of watertight closing.
- (b) Where a recess in the freeboard deck extends to the sides of the ship and is in excess of one meter in length, the lowest line of the exposed deck and the continuation of that line parallel to the upper part of the deck is taken as the freeboard deck.




1) International Convention on Load Lines 1966, ANNEX1 Chapter 1, Reg.3-(9), 2003

sydlab 75

Definition of Freeboard Length

Freeboard Length $(L_i)^2$:

- (a) The length shall be taken as 96% of the total length on a waterline at 85% of the least moulded depth measured from the top of the keel (L₁), or as the length from the fore side of the stem to the axis of the rudder stock on that waterline (L₂), if that be greater.
- (b) For ships without a rudder stock, the length (L) is to be taken as 96% of the waterline at 85% of the least molded depth.



Determination of Freeboard Deck The freeboard deck of the container carrier: Because there is a recess in the upper deck of the container carrier, the upper deck is discontinuous. Recess in **Upper Deck** upper deck Freeboard Deck Volume of pulded displacement at 85% Dmld 70165.4 m **Upper Deck** Freeboard Deck **Scantling Draft** FNGTH RETWEEN PERPENDICULAR (LBP) = Therefore, the freeboard deck of the container carrier is the second deck. sydlab 77

