

# Dispersion

Dr Yoonchan Jeong

School of Electrical Engineering, Seoul National University

Tel: +82 (0)2 880 1623, Fax: +82 (0)2 873 9953

Email: [yunchan@snu.ac.kr](mailto:yunchan@snu.ac.kr)

# Dispersion in SMF

## □ Types of Dispersion

### - Chromatic dispersion

Material dispersion

Waveguide dispersion: usually *smaller* than material dispersion

Short wavelength: The effective index is close to  $n_{core}$ .

Long wavelength: The effective index is close to  $n_{cladding}$ .

### - Modal dispersion

Pulse spreading in a multimode fiber

**Dispersion is a problem in fiber communications: It limits the *bandwidth* of the fiber.**

# Material dispersion

White light that is a mixture of colors can be separated into different wavelengths.

**Natural Dispersion: RAINBOW**

Refractive index  $n$  is inherently a function of wavelength.

Recall Snell's law!

$$n_i \sin \theta_i = n_t \sin \theta_t$$

# Material dispersion

e.g. Sellmeier equation:

$$n^2(\omega) = 1 + \sum_{j=1}^m \frac{B_j \omega_j^2}{\omega_j^2 - \omega^2}$$

The origin of chromatic dispersion is related to the characteristic resonance frequencies at which the medium absorbs the electromagnetic radiation through oscillations of bound electrons.

→ Kramers-Kronig relations:

$$\varepsilon(\omega) = \varepsilon_r(\omega) + i\varepsilon_i(\omega)$$

The real and imaginary parts are related to each other.

*(cf. Driven harmonic oscillator)*

*See also Classical Electrodynamics, J. D. Jackson*

# Dispersion relation

Mode-propagation constant  $\beta$  in a Taylor series:

$$\beta(\omega) = n(\omega) \frac{\omega}{c} = \beta_0 + \beta_1(\omega - \omega_0) + \frac{1}{2} \beta_2(\omega - \omega_0)^2 + \dots,$$

$$\text{where } \beta_m = \left( \frac{d^m \beta}{d\omega^m} \right)_{\omega=\omega_0} \quad (m = 1, 2, 3, \dots)$$

$$\beta_1 = \frac{1}{v_g} = \frac{n_g}{c} = \frac{1}{c} \left( n + \omega \frac{dn}{d\omega} \right), \quad \rightarrow \text{Group velocity}$$


$$\beta_2 = \frac{1}{c} \left( 2 \frac{dn}{d\omega} + \omega \frac{d^2 n}{d\omega^2} \right), \quad \rightarrow \text{Group velocity dispersion}$$

$$\psi(z, t) = \int_{-\infty}^{\infty} A(\omega) e^{i(\omega t - \beta(\omega)z)} d\omega \quad \leftarrow \text{Wave packet}$$


# Waveguide dispersion

The effective mode index is slightly lower than the material index  $n(\omega)$  of the core, which is also wavelength dependent.


Single-mode fiber (SMF)



Dispersion-compensation Fiber (DCF)



# Dispersion in SMF



Source: Nonlinear Fiber Optics, G. P. Agrawal


Dispersion parameter:

$$D = \frac{d\beta_1}{d\lambda} = -\frac{2\pi c}{\lambda^2} \beta_2 \approx \frac{\lambda}{c} \frac{d^2 n}{d\lambda^2}$$

**Normal dispersion:**  $\beta_2 > 0$  or  $D < 0$   
 High-freq. components *slower* than  
 low-freq. components

**Anomalous dispersion:**  $\beta_2 < 0$  or  $D > 0$   
 High-freq. components *faster* than  
 low-freq. components

# Walk-off in SMF



Source: Nonlinear Fiber Optics, G. P. Agrawal

Walk-off parameter:

$$d_{12} = \beta_1(\lambda_1) - \beta_2(\lambda_2) = \frac{1}{v_g(\lambda_1)} - \frac{1}{v_g(\lambda_2)}$$

Walk-off length:

$$L_W = \frac{T_0}{|d_{12}|}$$

e.g.  $\lambda_1 = 532 \text{ nm}$ ,  $\lambda_2 = 1064 \text{ nm}$

$$d_{12} \approx 80 \text{ ps/m}$$

$$L_W = 25 \text{ cm for } T_0 = 20 \text{ ps}$$



# Polarisation-mode dispersion (PMD)

Birefringence:

$$B_m = \frac{|\beta_x - \beta_y|}{k_0} = |n_x - n_y|$$

Beat length:

$$L_B = \frac{2\pi}{|\beta_x - \beta_y|} = \frac{\lambda}{B_m}$$


## Modal dispersion

Optical path differences among modes → different group velocity.


$$v_{g,m} = \frac{d\omega}{d\beta_m}$$

# Data Transmission over SMF

## ■ Initial Optical Pulses (10 Gbps, 0 dBm)



## ■ After 50-km Transmission



■ Group velocity dispersion (GVD)  
⇒ Frequency chirp

■ Nonlinear effect  
⇒ Four-wave mixing (FWM)

## ■ Power Spectrum

